



Galleria San Marco 4

33170 Pordenone

Tel. 0434 28465

Fax 0434 28466

E-mail: info@csi-italia.eu

Web: <http://www.csi-italia.eu>



User Manual

COPYRIGHT

Copyright © CSi Italia Srl. 2006 -2020
All rights reserved.

The CSI Logo®, SAP2000®, ETABS®, SAFE®, are registered trademarks of Computers & Structures, Inc.

Windows® is a registered trademark of the Microsoft Corporation.

Adobe® and Acrobat® are registered trademarks of Adobe Systems Incorporated.

The computer program VIS® and all associated documentation are proprietary and copyrighted products. Worldwide rights of ownership rest with CSi Italia Srl. Unlicensed use of these programs or reproduction of documentation in any form, without prior written authorizations from CSi Italia Srl., is explicitly prohibited. No part of this publication may be reproduced or distributed in any form or by any means, or stored in a database or retrieval system, without the prior explicit written permission of the publisher.

Further information and copies of this documentation may be obtained from:
CSi Italia Srl.

<http://vis.csi-italia.eu/>

info@csi-italia.eu (for general information)

support@csi-italia.eu (for technical support)

DISCLAIMER

Given the state of the art and the limits of computer science, CSi Italia cannot guarantee that the program and its manuals are entirely free of errors.

Considerable time, effort and expense have been devoted to the development and testing of this software and the associated documentation, however, by choosing to make use of it, the user agrees and understands that no guarantee of the program accuracy and reliability is expressed or implied by the developer or distributor.

The program is intended only to provide information to the user but not to replace him in his professional judgment. It is the user's responsibility to understand the basic assumptions of the software, compensate for aspects not addressed, and independently verify the results.

Index

1. PART I: Introduction.....	9
1.1. General	9
1.2. Operation Modes.....	9
1.3. Use as a SAP2000/CSiBridge Post-Processor	10
1.3.1. Installing VIS as a Plug-in.....	10
1.3.2. The SAP2000/CSiBridge Model	10
1.3.3. Section Cutter	11
1.3.4. Import	16
1.3.5. Design Process	16
1.3.6. Partial Import	17
1.3.7. Updating Imported Models.....	17
1.4. Use as ETABS Post-Processor	17
1.4.1. Installing VIS as a Plug-in.....	17
1.4.2. The ETABS Model	18
1.4.3. Import, design and updating of models	19
1.5. Use as Self-Standing Program	19
1.6. Combinator	19
2. PART II: Basic manual.....	23
2.1. Columns and Beams.....	23
2.2. Walls	23
2.3. Reference Systems.....	24
2.3.1. Frame Section Reference Systems	25
2.3.2. Wall Section Reference Systems	26
2.3.3. Examples	27
3. PART III: Reference manual.....	32
3.1. Definitions.....	32
3.2. The Main Window.....	33

3.2.1.	The navigation tab	34
3.2.2.	Display window – 3D tab.....	35
3.2.3.	Display window – Frame tab.....	36
3.2.4.	Display window – Wall tab.....	38
3.2.5.	Properties tab	39
3.3.	The “Application” menu	39
3.4.	The “General Settings” Ribbon Tab	40
3.4.1.	Code Selection	40
3.4.2.	General design parameters.....	40
3.4.3.	Seismic design parameters	44
3.4.4.	Serviceability design Settings.....	45
3.5.	The “Define” Ribbon Tab	46
3.5.1.	Default Materials	46
3.5.2.	Objects	48
3.5.3.	Internal Forces	57
3.5.4.	Groups.....	60
3.6.	The “Edit” Ribbon Tab.....	60
3.6.1.	Concrete and Steel.....	60
3.6.2.	Slenderness Factor	60
3.6.3.	Seismic Bending	61
3.6.4.	Segments.....	61
3.6.5.	Walls reinforcing	65
3.6.6.	Joints reinforcing.....	71
3.6.7.	Seismic Relevance of Members	71
3.6.8.	Wall transverse shear.....	71
3.7.	The “Design Wizard” Ribbon Tab.....	71
3.7.1.	Configuration parameters.....	72
3.7.2.	Frames reinforcing parameters.....	73
3.7.3.	Walls reinforcing parameters.....	75
3.7.4.	Run	76

3.8. The “Strength” Ribbon Tab	76
3.8.1. PMM Design of Single Frame Elements	77
3.8.2. Shear Design of Single Frame Elements	78
3.8.3. Design of Frame Elements All At Once.....	79
3.8.4. PMM Design of a Single Wall	79
3.8.5. Shear Design of a Single Wall	81
3.8.6. Design of Walls All At Once	82
3.8.7. PMM Check of Single Frame Elements	82
3.8.8. Shear Check of Single Frame Elements	86
3.8.9. Checks of Frame Elements All At Once	87
3.8.10. PMM Check of Single Wall-Stacks.....	88
3.8.11. Shear Check of Single Wall-Stacks.....	89
3.8.12. Checks of All Walls At Once	90
3.8.13. Joints check	90
3.9. The “Capacity” Ribbon Tab	91
3.9.1. Design for Strong-Column Weak-Beam Action at Single Joints	92
3.9.2. Shear Design of Single Beam-Column Joints.....	93
3.9.3. Shear Design of Single Frame Elements	94
3.9.4. Design of Frame Members All At Once	95
3.9.5. PMM Design of a Single Wall	95
3.9.6. Shear Design of a Single Wall	96
3.9.7. Design of Wall All At Once	97
3.9.8. Check for Strong-Column Weak-Beam Action at Single Joints	97
3.9.9. Shear Check of Single Beam-Column Joints	98
3.9.10. Shear Check of Single Frame Elements	99
3.9.11. Checks of Frame Members All At Once.....	100
3.9.12. PMM Check of Single Wall-Stacks.....	100
3.9.13. Shear Check of Single Wall-Stacks.....	101
3.9.14. Checks of All Walls At Once	103
3.10. The “Serviceability” Ribbon Tab	104

3.10.1.	Stress Limitation Checks of Single Frame Elements	104
3.10.2.	Crack Control Check of Single Frame Elements	105
3.10.3.	Checks of All Frame Elements At Once	106
3.11.	The “Detailing provisions” Ribbon Tab	106
3.11.1.	Check of Single Frame Elements	107
3.11.2.	Check of Single Joints	109
3.11.3.	Check of Single Walls	109
3.11.4.	Checks of All Frame Members At Once	109
3.12.	The “Results” Ribbon Tab	109
3.12.1.	Strength Tables	110
3.12.2.	Capacity Tables	110
3.12.3.	Serviceability Tables	111
3.12.4.	Detailing Provisions Tables	111
3.12.5.	Log Table	112
3.12.6.	Delete results	112
3.12.7.	Show ratios	112
3.12.8.	PMM 3D Interaction Diagram	112
3.12.9.	Ellipse of Inertia	113
3.12.10.	Reinforcing layouts	113
3.12.11.	Report	114
3.13.	The “View” Ribbon Tab	114
3.13.1.	View type	115
3.13.2.	Set view	115
3.13.3.	Show/Hide	116
3.13.4.	Reinforcing contours	116
3.14.	Additional export capabilities	116

PART I: Introduction

1.1. General

VIS is a software suite for the design and check of concrete members: beams, columns, walls piers and spandrels. The reference codes currently implemented are:

- Current Eurocode1992: EC2-2005 - Concrete design;
- Current Eurocode 1998: EC8-2005 - Seismic design.

Four design areas are investigated:

- strength: including PMM interaction, shear strength, slenderness;
- capacity: including weak beam strong column action, shear capacity at columns, beams and joints, moment and shear magnification at walls;
- serviceability: including stress limitation and cracking;
- detailing provisions: including limits of reinforcement and of concrete geometry constraints, for both non-seismic and seismic conditions.

The suite is made up of four separate programs, precisely:

- Combinator, for the automatic generation of load combinations according to EC1 in SAP2000, ETABS and CSiBridge;
- Section Cutter, for the automatic generation of Piers and Spandrels in SAP2000 and CSiBridge;
- VIS, the main program for the design and check of members;
- SPF, an optional module for the automatic seismic evaluation of existing RC structures.

1.2. Operation Modes

Two autonomous operation modes are available for the program:

- As a post-processor for SAP2000/ETABS/CSiBridge;
- As a self-standing program.

The two modes can be combined during a single work session.

The post-processing mode is the preferred mode.

1.3. Use as a SAP2000/CSiBridge Post-Processor

1.3.1. Installing VIS as a Plug-in

VIS can function as a plug-in, directly from within SAP2000 or CSiBridge. The procedure is generally automated. If the auto install procedure succeeds, the VIS program will be listed among the plug-ins in the SAP2000/CSiBridge “Tools” menu.

Certain conditions may require the plug-in to be installed manually. In such cases, proceed using one of the following two methods:

- close SAP2000 and/or CSiBridge;
- Launch the application “RegisterAll.bat” located inside the main installation folder of the VIS suite (typically C:\Program Files\CSI Italia).
- As an alternative, to register the main program only, launch the application “RegisterPlugin.exe” that can be found inside the VIS installation folder.

If the previous approaches did not work, it can be possible to manually register the plugin following these steps:

- Run SAP2000/CSiBridge and enter the “Tools” menu;
- Click on “Add/Show Plug-Ins...”;
- From the installation window, enter the following:
 - On first column: CSiItalia_VIS13;
 - On second column: VIS 13;
- Click the “Add” button.

1.3.2. The SAP2000/CSiBridge Model

In order for the SAP2000/CSiBridge model to be correctly imported and become a VIS model, certain criteria need to be followed:

- the elements material to be imported needs to be of type “Concrete”.
- Beams and columns need to be modelled with a single frame element per span/story. The variable reinforcing along the length of the elements will be defined directly in VIS.
- The frame element sections can be defined through the parametric definition window (concrete rectangular, L, T and circle) or through section designer. In the latter case the sections should be made up by a unique polygon (with generic shape) and, optionally, a set of internal openings.
- In order for a frame element to be recognized by VIS as a column, it needs to be vertical (parallel to the Z-axes). All other frame elements will be defined as beams. It will be always possible to convert elements from beam to column and vice versa using the command Define > Frame > Convert.

- Wall piers and spandrels need to be defined using shell elements having concrete materials.
- The wall sections, which will be designed by VIS, are defined using SAP2000/CSiBridge Section Cuts. Typically, pier section cuts are taken at the top and bottom of each floor or (coupling beams) while spandrel sections at the two ends of the beam. Generation of the section cuts is facilitated by a separate plug-in tool called “Section Cutter”. Use of Section Cutter tool is explained in the following paragraph.


1.3.3. Section Cutter

Walls can be defined in the SAP2000/CSiBridge model using arrays of concrete shell elements. For the walls to be imported into the VIS model, they need to be preliminarily cut into a series of sections. These section cuts are taken at a finite number of locations along the length of the wall and organized into Wall-Stacks.

The sections of each stack define the wall geometry (length, width, etc.) and internal forces. Depending on the geometry, the sections can be assigned either a “Pier” or “Spandrel” behavior.

A section is given:

- Pier behavior if the section’s normal axis has non zero vertical component;
- Spandrel behavior if the section’s normal axis is horizontal.



Within a single Wall-Stack, all section cuts need to be homogeneous, either Pier or Spandrel. If they are not, all cuts, whose type differs from the first, are discarded.


Being derived directly from the layout of imported shell elements, the geometry of wall sections cannot be modified by the user, once imported into the VIS model and therefore would need to be rerun from the original import if incorrect.

From a modeling perspective a wall can have a generic shape, however its design sections (section cuts) must be represented by a connected polygon. Therefore, whenever the layout of the wall openings determines the formation of disconnected parts, it will be necessary to create different walls for each independent portion through "Section Cutter".

The "Section Cutter" tool provides a set of built in functionalities which can help the user in creating section cuts inside the structural mesh. This tool can be run directly through the SAP2000/CSiBridge "Tools" menu. If, after the installation of the VIS suite, the plugin is not visible, run the "RegisterPlugin.exe" application located in the Section Cutter installation folder.

The program offers three different operational approaches:

- Define vertical wall – automatic creation of wall piers from a selection of shell elements;
- Define coupling beam – automatic creation of wall spandrels from a selection of shell elements;
- Define section cuts – automatic creation of section cuts from SAP2000/CSiBridge's groups.




Define vertical wall

This command allows to define a set of piers starting from a selection of shell elements.

At this purpose it is necessary to select the shell elements which make up the wall and click on the corresponding command. It will then be possible to assign a name

to the wall (which must not include the symbol “_”) and identify the section cuts to be created. Section Cutter automatically creates section cuts at every grid plane in the Z direction. It is also possible to create additional sections at different elevations by simply selecting one or more joints corresponding to that elevation and activating the option "At selected Joints". For composite piers, with more than one leg, it is also possible to select the approach to be used for shear design: by activating the option “Create separate legs for shear check” the program will create additional section cuts for each leg of the wall while, on the contrary, the design will be based on the global forces of whole section. For more information, please refer to the corresponding section of the VIS Design Manual.

Click the "OK" button to create the corresponding section cuts. A summary window will finally report the result of the operation showing potential errors occurred during the process.




Define coupling beam

This command allows to define a set of spandrels starting from a selection of shell elements.

At this purpose it is necessary to select the shell elements which make up the coupling beam and click on the corresponding command. It will then be possible to assign a name to the beam (which must not include the symbol “_”) and identify

the section cuts to be created. Section Cutter automatically creates section cuts at both ends of the beam. It is also possible to create additional sections at different stations along the beam by simply selecting one or more joints corresponding to that location and activating the option "At selected Joints".

Click the "OK" button to create the corresponding section cuts. A summary window will finally report the result of the operation showing potential errors occurred during the process.



Define section cuts

Use this form to generate section cuts based on "Groups" previously defined within SAP2000/CSiBridge.

In order for the section cuts to be recognized and imported by VIS, they need to be defined into the model using groups containing nodes and elements and defined according to specific rules. Precisely:

- Section cut groups should include all the joints along the cut line plus all of the elements on either side of the section. The joints define the cut location and the elements define the side of the section cut to which the internal forces refer. This

could be significant at floor lines or other discontinuous locations where the wall internal forces on either side are different;

- Groups could come in any number along the length of the pier or spandrel. Their number and location should be chosen by the user to maximize information on wall behavior: e.g. at both sides of discontinuous lines;
- Ideally, pier section cut groups should come in pairs, taken at any given level, just above and below the floor line. In order to do this, each section cut group should include the floor line and all the elements below, or all the elements above, depending on whether the section is a top or bottom section for the pier at that level; Spandrel section cut groups could be many, counting at least one at each end of the spandrel.
- In order to build Wall-Stacks, the groups should be named by the user using the following syntax:


WALL STACK ID _ PROGRESSIVE NUMBER

"WALL STACK ID" refers to the name given to the pier or spandrel being defined and should not include the symbol "_", while "PROGRESSIVE NUMBER" specifically defines the section cut along the Wall-Stack. Within a certain pier or spandrel the Wall-Stack ID should remain the same, while the number should vary with each section. It is suggested that the numbers are assigned in a consecutive fashion, increasing from the bottom up or from one side to the other. An alphanumeric string could be attached at the end: e.g. "Wall1_3Top" could be used to identify a section cut taken at the top of the third floor of wall 1.

Click the "OK" button to convert all available groups into Section Cuts. A summary window will finally report the result of the operation showing potential errors occurred during the process.

If not all groups need to be converted, select those to be excluded and press the "CANC" button from the keyboard.

To overwrite previously defined Section Cuts, click the "Section Cut Overwrite" selection box.



1.3.4. Import

To import the model from SAP2000/CSiBridge to VIS adhere to the following steps:

1. Open SAP2000/CSiBridge and run the analysis;
2. Start VIS from the “Tool” menu;
3. Choose the load patterns and combinations you wish to design for.

1.3.5. Design Process

Once the model has been imported, proceed to the design and check of the various elements:

1. From the toolbar in the lower right corner, select the units of preference. These settings can be changed at any time, as needed.
2. From the “General Settings” tab, select the preferred code and the other relevant settings.
3. From the “Wizard” tab, set the reinforcing preferences for beams, columns, piers and spandrels and click the “Run all” button. Once the design process is completed, look for potential error and warnings notified in the status bar of the program. Since the design process carried out by the Wizard is iterative, it can be possible that some or all the design errors reported have been resolved in subsequent iterations. For this reason, detailed checks must be performed as described at point 4.
4. Run the checks for the different limit states using the command “Frames all” and “Walls all” of the “Strength”, “Capacity”, “Serviceability” and “Detailing provisions” tabs.
5. From the “Results” tab, revise the D/C ratios for the different limit states either in a graphical or tabular form. If some elements do not meet some design requirement it is possible to look more in the details of the calculation simply by selecting the element and running the corresponding commands inside the “Strength”, “Capacity”, “Serviceability” or “Detailing provisions” tab.
6. Use the “Edit > Segments > Edit reinforcing” command to look at and modify the reinforcing assigned to beams and columns. In the same way revise and edit the walls reinforcing using the “Edit > Wall reinforcing > Edit reinforcing” command. Inside both the environments all the checks can be easily re-executed in order to evaluate the effectiveness of the changes made.
7. Once the revision of the reinforcing has been completed run again the collective checks for all the different limit states as described at point 4.
8. Once the final result has been determined create the calculation report through the “Results > Report > Create” command. It is also possible to export the detailed reinforcing layouts for the different elements using the “Results > Reinforcing layout > Export” button.

1.3.6. Partial Import

Importing from SAP2000/CSiBridge can include the entire model, or just a portion of the model. This option can be useful in containing the size of the portion of structure being designed when the model is significantly large.

To do a partial import, while still working with SAP2000/CSiBridge, a "Selection" of all the elements to be designed must be completed first, then start VIS from the SAP "Tool" menu. Then proceed with the import procedures defined in paragraph 1.3.4.

Partial import is currently available only for frame elements. To avoid the import of certain shell elements you can specify which area section should be skipped directly in the import settings window.

1.3.7. Updating Imported Models

If changes need to be made to the SAP2000/CSiBridge model and the existing VIS model needs to be updated consequently, follow this procedure:

- save the VIS model corresponding to the previous revision and close the program;
- modify the SAP/CSiBridge model as desired and start VIS again from the "Tool" menu;
- import the model as a new VIS model, save the file, close the program and open the new file directly in VIS;
- open the application menu and click the command "Import Reinforcing", then select the model corresponding to the previous revision as source model;
- the reinforcing of all the members that did not undergo to geometrical changes will then be imported;
- set the code preferences from the General Settings tab.

With such approach it will be possible to handle any change to the structural model without losing the reinforcing layout assigned to the elements that have not been modified from one revision to another.

1.4. Use as ETABS Post-Processor

1.4.1. Installing VIS as a Plug-in

VIS can function as a plug-in, directly from within ETABS (from v16.0.0). The procedure is generally automated. If the auto install procedure succeeds, the VIS program will be listed among the plug-ins in the ETABS "Tools" menu.

Certain conditions may require the plug-in to be installed manually. In such cases, proceed using one of the following two methods:

- Close SAP2000 and/or CSiBridge;
- Launch the application "RegisterAll.bat" located inside the main installation folder of the VIS suite (typically C:\Program Files\CSI Italia).
- As an alternative, to register the main program only, launch the application "RegisterPlugin.exe" that can be found inside the VIS installation folder.

If the previous approaches did not work, it can be possible to manually register the plugin following these steps:

- Run ETABS and enter the "Tools" menu;
- Click on "Add/Show Plug-Ins...";
- From the installation window, enter the following:
 - On the "Plugin Name" column: CSiItalia_VIS13;
 - On the "Menu Text" column: VIS 13;
- Click the "Add" button.

1.4.2. The ETABS Model

In order for the ETABS model to be correctly imported and become a VIS model, certain criteria need to be followed:

- The elements material to be imported needs to be of type "Concrete".
- Beams and columns need to be modelled with a single frame element per span/story.
- The frame element sections can be defined through the parametric definition window (concrete rectangular, L, T and circle) or through section designer. In the latter case generic polygonal sections are not handled. If a certain section is not recognized during the import, VIS will still import the related member and will assign it a generic section shape. In this way it will be straightforward to re-define the real geometry in the VIS program.
- In order for a frame element to be recognized by VIS as a column, it needs to be vertical (parallel to the Z-axes). All other frame elements will be regarded as beams. It will be always possible to convert elements from beam to column and vice versa using the command Define > Frame > Convert.
- Wall piers and spandrels need to be defined in the ETABS model using wall elements and appropriate piers/spandrel labels. Typically, the same label should be used from the bottom story to the top story of continuous piers: VIS will then automatically organize the different sections by elevation inside the same wall stack. Also, spandrel which couple different story of the same piers can have the same label: VIS will create a different coupling beams for each story.

From a modeling perspective a wall can have a generic shape, however its design sections ("Pier labels" and "Spandrel labels") must be represented by a connected polygon. Therefore, whenever the layout of the wall openings determinates the formation of disconnected parts, it will be necessary to create different "Pier/Spandrel labels" for each independent portion.

1.4.3. Import, design and updating of models

For the import, design and updating of models please refer to §1.3.4, 1.3.5 and 1.3.7.

1.5. Use as Self-Standing Program

VIS can be used autonomously to design and check single sections or very small models. Walls can only be imported from SAP2000/ETABS/CSiBridge.

- Open VIS by itself using the executable icon from the computer desktop (or where it has been saved) or through the VIS directory. Set current codes and materials from the proper ribbon tabs and set the current units from the selector button on the right side of tool bar.
- From the "Define" tab:
 - click the "Joints" button to define structural nodes;
 - click the "Sections" button to define sections;
 - click the "Frames" button to insert frame elements (columns and beams), assigning their end joints, their section and the number of segments they need to be divided into;
 - click the "Forces" button, to assign a set of internal forces. For each segment, specify, as required, several sets of forces deriving from various load combinations.
- Complete the above for all of the structural members to be designed.
- For design and check, follow the instructions previously provided in paragraph 1.3.5.

1.6. Combinator

Combinator is a plug-in application for the generation of load combinations sets based on Eurocodes provisions. The tool can be run directly from the SAP2000/ETABS/CSiBridge "Tools" menu. If, after the installation of the VIS suite,

the plugin is not visible, run the "RegisterPlugin.exe" application located in the Combinator installation folder.

The workflow is very simple:

- While working with SAP2000/ETABS/CSiBridge, define the desired load cases.
- Open Combinator from the "Tools" menu (in CSiBridge remember to execute Combinator within the "menu" interface and not within the "ribbon" interface).
- Assign to each load case or combination the proper type and category, as defined in EC-1.

Load case / Combination	Load type
DEAD	G1
DEAD2	G2
OFFICE	Qb
CORRIDOR	Qc
ROOF	G1
OFFICE2	G2
SNOW	P
	Qa
	Qb
	Qc
XQUAKE	Qd
YQUAKE	Qe
	Qf
	Qh
	QS1
	QS2
	QT
	QW
	Ex
	Ey
	Ez
	ECCx
	ECCy

- Set the filters deemed adequate to limit the number of combinations. Meaningless or redundant combinations should be avoided, to reduce calculation time and improve clarity.

Filters

☒ Min G1 + min G2 + max (Qvertical, Temperature)

☐ MinG1 + min G2 + max (Wind and related Qvertical, Temperature)

☒ Min G1 + min G2 + max (Temperature and related Qvertical, Wind)

☒ Min G1 + max G2 + min Q

☒ Min G1 + max G2 + max (Qvertical, Temperature, Wind)

☒ Max G1 + min G2

☒ Max G1 + min G2 + max (Qvertical, Temperature, Wind)

☐ Min G1

☐ Min G2


☐ Min Q

- Select the Limit States for which the Combinations should be generated. These are the reference limit states from EC- 0. Precisely:

STR	Structural (non Seismic) ULS
QKE	Seismic ULS
EQU	Equilibrium ULS
GEO	Geotechnical ULS
CHR	Characteristic SLS
FRQ	Frequent Service SLS
QPR	Quasi-Permanent SLS

More Limit States can be selected at the same time.

- Select the summation mode. Either Linear or Range add. This is intended for checkered live load patterns. See SAP/ETABS User Manual. Range add combinations can be applied to all Loads Patterns having the same type.



- Review the results, from the combination spreadsheet, and edit where required.

Combination	LoadCase	Factor	Combination type
	ROOF	1.05	
STR53	COMBO_DEAD	1	LINEAR ADD
	COMBO_LIVEC	1.05	
STR54	COMBO_DEAD	1.35	LINEAR ADD
STR55	COMBO_DEAD	1.35	LINEAR ADD
	ROOF	1.05	
	SNOW	0.75	
STR56	COMBO_DEAD	1.35	LINEAR ADD
	COMBO_LIVEC	1.05	

-
- Click the OK button to save the combinations and return to SAP2000/ETABS/CSiBridge. All the combinations are now included into the model and can be viewed from the Define > Load Combinations window.

PART II: Basic manual

2.1. Columns and Beams

Frame elements imported from the SAP model are treated by VIS as columns or as beams. By default, vertical elements are treated as columns and all other elements as beams. The user can change the default settings, as preferred, on an element-by-element basis. The distinction between Columns and Beams has several implications. More precisely:

- Strength design of Beams is carried out only for moment M3 and shear V2. Axial load should be null or very small. If not, an error message is reported.
- For strength design, Beams are considered to have only top and bottom longitudinal reinforcing, plus vertical stirrups.
- Strength design of double reinforced Beams can have infinite solutions. The result is made univocal assigning a steel target strain (default is 0.005).
- Beam checks do not have the previous limitations: biaxial bending and axial force are admitted and reinforcing can have any layout.
- Strength design of Columns assumes the reinforcing design area to be uniformly distributed among all rebars. The rebar location needs to be set by the user. The default setting is one rebar at each corner.
- Slenderness calculations are carried out for columns only.
- The distinction between columns and beams necessarily affects all areas of capacity design calculations (weak beam - strong column design, shear capacity of columns and beams, shear capacity of joint panels).
- The distinction between columns and beams also significantly affects various checks for code limits of reinforcing and geometrical provisions.

2.2. Walls

Walls can be defined in the SAP2000/ETABS/CSiBridge model using arrays of vertical concrete shell elements. For the walls to be imported into the VIS model, they need to be preliminarily cut into a series of sections either using "Section Cutter" (SAP and CSiBridge models) or assigning a proper "Pier" or "Spandrel" label (ETABS models). These section cuts are taken at a finite number of locations along the length of the wall and organized into Wall-Stacks.

2.3. Reference Systems


The program utilizes the same reference systems used by SAP: there are **global** and **local** reference systems. All reference systems are right-handed.

Global axes X, Y and Z define joint locations in the model global geometry.

Element local axes, **1**, **2** and **3**, are used as a reference system for the element internal forces.

Sections have **principal axes** as well. The principal axes for a given section, Major and Minor are those with maximum and minimum inertia.

The picture below shows the sign convention used for local and principal axes, bending moments, radii of gyration and effective length. The local **1** axis is directed toward the observer.



ρ_{major} radius of gyration (major axis)

e_{major} eccentricity (major axis)

K_{major} effective length factor (major axis)

$$\lambda_{major} = \frac{K_{major} \cdot l}{\rho_{major}}$$

With reference to the picture before:

- Compression axial loads are negative; tension axial loads are positive.

- Positive bending moments cause compression at the positive face of the local axis.
- Positive shear forces have the same direction of local axes.


The effective length factors need be defined with reference to the principal axes. Conventionally K_{major} refers to restraints acting on major axis moments, while K_{minor} refers to restraints acting on minor axis moments.

For slenderness calculations, the program converts the internal forces from the local to the principal axes reference system.

2.3.1. Frame Section Reference Systems

Frame sections can be viewed clicking on the “Frame” tab, at the lower right corner of the main window after a frame element is selected. Sections are represented in accordance with the following conventions:

- Element local axis 1 is perpendicular to the section and points toward the user;
- Element local axes 2 and 3 are oriented as in the SAP model, run through the section centroid, and can rotate as required;
- There is also a section local coordinate system, used to identify the location of the installed rebar and vertexes. The x and y-axes are horizontal and vertical respectively and the origin is chosen by user.
- The section upward direction, y, is parallel to the global Z-axis for beams, and parallel to the global X-axis for columns.



2.3.2. Wall Section Reference Systems

If the model is imported from ETABS, the wall reference system match exactly the ETABS's reference system; whereas if the model is imported from SAP2000 or CSiBridge, VIS automatically builds its own local reference system as described in the following paragraphs.

There are two types of wall sections: pier sections and spandrel sections. The local reference systems of each have different conventions.

Pier sections

- The pier local axis 1 is parallel to the global Z-axis and points up;
- The section is always perpendicular, with the pier local axis 1 pointing toward the user;
- Axes 2 and 3 belong to the section plane and are oriented parallel or perpendicular to the section's longer arm. Where:
- if the longer arm falls within $\pm 45^\circ$ from the global X axis, then the local 3 axis is parallel to that arm, otherwise it is perpendicular;
- axis 3 points away from the positive global Y direction. If it is parallel to the global X axis, it points away from the positive global X direction;
- Axis 2 direction can be deduced applying the right hand rule, so that:
 $V_2 = V_3 \times V_1$

Spandrel Sections

- The section local axis 1 runs along the spandrel axes. It is parallel to the global XY plane and points in the general direction of the positive global X axis. If parallel to Y, it points in the positive Y direction;
- The section local axes 2 and 3 belong to the section plane and are parallel or perpendicular to the direction of the longer side of the spandrel section;
- Axis 2 is set as follows:
- the longer section side is identified and its angle with the Z axis is calculated;
- if this angle is within $\pm 45^\circ$, axis 2 is parallel to the longer side; otherwise axis 2 is perpendicular;
- axis 2 direction is in the general direction of the positive global Z axis;
- axis 3 is consequently defined using the right hand rule, so that
 $V_1 \times V_2 = V_3$

2.3.3. Examples

Simple Wall Pier in the XZ Plane

This pier has a simple, single leg section and is parallel to the global ZX plane. Loads are applied at top. Where:

$$F_x = -10 \text{ kN} \qquad F_y = +20 \text{ kN} \qquad F_z = +30 \text{ kN}$$


The control section is taken one meter below the top of the wall. Two section cuts are defined: one using the elements above the section line and one using the elements below the section line.

The resulting internal forces are necessarily the same. Where:

$$N = +30 \text{ kN}$$

$$V_2 = +20 \text{ kN} \qquad M_3 = +20 \text{ kNm}$$

$$V_3 = +10 \text{ kN} \qquad M_2 = +10 \text{ kNm}$$




Assembled Wall Pier


Wall piers can also have complex sections. In this case, large wall assemblies, like elevator or staircases, can be treated as a single entity. The resultant of the external forces is calculated and applied at the centroid of the assembled section. The reinforcing is designed assuming the entire section remains planar and acts as that of a single pilaster.

User sensibility should limit this approach to relatively compact and slender wall assemblies.

In this example, the pier section has three legs forming a C shape: the flanges are parallel to the global X-axis and the web is parallel to the global Y-axis.

Note location and orientation of local axes and the global axes.





Wall Spandrel in the YZ Plane

This spandrel is parallel to the global ZY plane and acts as a cantilever with applied loads at the free end.

Where:

$$F_y = +10 \text{ kN}$$

$$F_x = -20 \text{ kN}$$

$$F_z = +30 \text{ kN}$$

The control section is taken one and a half meters from the free end. Independently from which side of the section cut the group elements belong to, the resulting internal forces are:

$$N = +10 \text{ kN}$$



$$V_2 = +30 \text{ kN}$$

$$M_3 = +45 \text{ kNm}$$

$$V_3 = +20 \text{ kN}$$

$$M_2 = +30 \text{ kNm}$$

Note that local axis **1** is now parallel to global axis Y



PART III: Reference manual

3.1. Definitions


- **Frame Element:** any column or beam (independent from restraint conditions). Each frame is identified by a name, or frame ID.
- **Section:** the concrete geometry and reinforcement layout of a frame or wall element. Each section is identified by a section ID.
- **Station:** a point along the frame element with known internal forces and sections. Each station is identified by the frame local 1 coordinate.
- **Segment:** a portion of frame element where the section (concrete geometry and its reinforcing) remains homogeneous. Segments along the frame element are identified by consecutively increasing numbers. A segment can include many stations.
- **Section Cut:** a section cut done through a number of shell elements from the SAP model. At each cut the wall section geometry and internal forces are imported from SAP, the rebar layout is defined by the user in the VIS model.
- **Wall:** a stack of wall sections having the same name and ordered by consecutively increasing numbers.
- **Pier:** a wall element where the section cuts are not vertical.
- **Spandrel:** a wall element where the section cuts are vertical.
- **Internal Forces:** all the internal forces, namely N, M3, M2, V3, V2, which affect a given station for a given load combination.

Note that the current VIS version does not support torsional moments.

- **Demand Capacity Ratio (D/C):** ratio between code required performance and the calculated capacity of a given element, segment, section.
- **Design:** the calculation of the minimum reinforcing required at each station to satisfy code requirements for a given load combination.
- **Check:** the calculations for the verification of a given section, with reinforcing already assigned, to withstand code-requirements. Results are presented in the form of D/C ratios. A positive check requires the D/C ratio to be lower than one. Successful checks are typically presented in green, otherwise in red.

3.2. The Main Window

The figure below shows the main window of the graphical user interface. The user can move or resize this window using standard operations.



Five different areas can be identified:

- **Ribbon (1):** the ribbon on the upper part of the main window includes all the program commands, organized in tabs and groups of commands according to a logical sequence;
- **Navigation Tab (2):** the navigation tab, on the left side, allows the user to navigate among the various items of the model. These items are arranged into six categories: Joints, Sections, Columns, Beams, Walls, and Groups. The user can perform several operations on these various items, including select, edit, delete, and assign. Right clicking the mouse provides access to all available operations also;
- **Display Window (3):** the display window, in the center, has three separate tabs which display the 3D model of the structure ("3D" tab) the internal segment subdivision of the selected frame element ("Frame" tab) or the internal section subdivision of the selected wall element ("Wall tab").
- **Properties Tab (4):** the tab on the right side of the main window provides useful information on the current selection. If more than one member is selected, the window reports the number of selected objects per type; while if only one member is selected the related detailed information are displayed (name, general and mechanical properties, commercial properties...).
- **Status Bar (5):** the status bar, at the bottom, reports several information. In the left side the informational and error messages that can arise after the check/design phase are reported through an appropriate icon. With a simple

click the related messages are displayed in a separate window. In right side the current code in use, the chosen ductility class, the coordinates of the cursor (if over an element section), and the units selector are displayed.

3.2.1. The navigation tab

The navigation tab organizes, by type, all the objects of the VIS model:

- the “Joints” group includes all the “structural” joints of the model. A joint is considered “structural” when it is directly connected to a beam or a column or is part of a wall section cut. To select any joint click on the corresponding check box; the joint will be also highlighted in the 3D interface (please note that the wireframe view should be set in order to make joint objects visible). Right-click on the joint label to access the dedicated action menu which allows for several operations (reinforcing definition, restraint conditions...).
- The “Sections” group includes, by type, all the sections defined in the model. If a single frame is selected, the section corresponding to the current segment is highlighted. Right-click on the section label to access the dedicated action menu which allows for several operations (editing, copying, duplication...).
- The “Beams” group includes, by type, all the beams defined in the model. To select any beam click on the corresponding check box; the element will be also highlighted in the 3D interface. Right-click on the beam label to access the dedicated action menu which allows for several operations (reinforcing editing, internal forces definition...).
- The “Columns” group includes, by type, all the columns defined in the model. To select any column click on the corresponding check box; the element will be also highlighted in the 3D interface. Right-click on the column label to access the dedicated action menu which allows for several operations (reinforcing editing, internal forces definition...).
- The “Walls” group includes, by type, all the walls defined in the model. To select any wall click on the corresponding check box; the element will be also highlighted in the 3D interface. Right-click on the wall label to access the dedicated action menu which allows for several operations (reinforcing editing, internal forces definition...).
- The “Groups” group includes all the groups defined in the model. Groups are a tool for memorizing complex multiple selections that the user can recall later, when these selections are needed again. Inside each group the objects are organized by type (beams, columns and walls). To select all the objects of a certain type click on the corresponding category.

3.2.2. Display window – 3D tab

The 3D tab inside the main display window shows the full 3D view of the model and allows for a direct interaction with beams, columns, joints and walls. In the upper part of the tab a dedicated command panel is present.



- The “Home” button restores the default view;
- The “Magnifying glass” button activates the magnifying tool and allows for an instant magnification of the portion of the model under the cursor position. To exit the command click again on the corresponding icon.
- The “Zoom window” button allows a direct zoom in a certain area through a rubber band selection. To exit the command click again on the corresponding icon.
- The “Zoom” button activates the dynamic zoom mode. By holding the mouse button and moving the cursor it is possible to zoom on precise regions of the model. To exit the command click again on the corresponding icon.
- The “Pan” button activates the pan mode. By holding the mouse button and moving the cursor it is possible to move the model over the graphical window. To exit the command click again on the corresponding icon.
- The “Rotate” button allow to rotate the model by simply holding the mouse button and moving the cursor on the screen. To exit the command click again on the corresponding icon.
- The “Zoom fit” command reset the zoom level so that the full model is visible maintaining the current viewpoint. To exit the command click again on the corresponding icon.

There are also some shortcuts that allow to manipulate the model quickly:

- to rotate the model place the cursor in a generic position of the 3D interface, press and hold the mouse wheel and move the cursor;
- to perform a pan place the cursor in a generic position of the 3D interface, press and hold the mouse wheel and the ‘Ctrl’ button and move the cursor;
- to zoom in a certain position place the cursor in the target region and then scroll the mouse wheel.

The “view cube” in the right upper part of the window allows for a quick viewpoint selection (by clicking on a certain face, edge or corner) and for dynamic rotation (by pressing and holding the mouse button and moving the cube).


To select a certain frame or joint click on it or use the rubber band selection. To add elements to an existing selection press and hold the 'Ctrl' button.

3.2.3. Display window – Frame tab

Each frame object of the model is identified by a label which, for imported models, coincides with the one defined in the SAP2000/CSiBridge/ETABS model. Each frame can be divided into one or more segments, identified by a progressive number along the member. Each segment can have its own section and there are no particular limitations to their number or geometry. In this way it is possible to reproduce a generic reinforcing arrangement along the element. As we will see in the later paragraphs, the segment subdivision can be done manually by the user or automatically by the program using the specific editing environments. Segments are ordered starting from the frame initial joint (joint I).

Managing the frames elements and the related segments through the graphical interface is rather easy:

- to select a certain frame click on the corresponding check box in the navigation tab or click directly on the element in the 3D view of the model;
- to navigate through the segments click on the "Frame" tab and use the dedicated selector in the upper part of the screen. A double click select the corresponding segment which will be highlighted in red. The name of the associated section is reported in the left upper part of the window and the corresponding geometry, local axes and reinforcing are shown in the center of the screen.



Within the “Frame” tab there are also some dedicated tools to customize the section reinforcing however, this is not the main purpose of this tab neither the recommended workflow. There are indeed other interactive and more productive tools, like the reinforcing editor, that allow for a detailed customization of the reinforcing of entire beam rows or column rows in fewer simple steps. All the different options are comprehensively described in 3.6.4. The “Frame” tab represents instead the primary tool to identify the internal layout of a certain frame and the related segments providing a prompt and exhaustive control over the model.

Given the above, the editing tools are available through the “Frame tools – Reinforcing” tab that appears in the ribbon menu when the “Frame” tab is selected. The available commands vary from the possibility to quickly assign a section to a given segment, to the ability to customize its reinforcement.

To assign a section to the current segment, right click on the section name inside the navigation tab and click “Assign”. The section can be selected among those with the same shape.

To customize the reinforcing of the current segment there are two possible approaches:

- **global editing** – that can be activated by selecting the “To all” button in the “Apply” tab of the “Frame Tools Reinforcing” ribbon menu. In this way all the changes applied through the quick editing commands, available on the right side of the tab or with a right click on the section draw, will be applied to all the segments across the model that shared the same section.
- **Local editing** – that can be activated by selecting the “Locally” button in the “Apply” tab of the “Frame Tools Reinforcing” ribbon menu. In this way all the changes applied through the quick editing commands, available on the right side of the tab or with a right click on the section draw, will be applied only to the current segment. In the case the section was shared between more segments, VIS will automatically create a copy of the section with a new name and assign it to the current segment. For example, if the segment had an original section called “R30x40”, after the editing VIS will create and assign to the segment a new section called “R30x40-1”.


Within the “Frame” tab it is also possible to view the coordinates of any point of the section polygon or longitudinal rebar by simply moving the mouse over the element: the corresponding coordinates will be reported in the lower right part of the “Status” bar.

3.2.4. Display window – Wall tab

Each wall object of the model is identified by a label which, for SAP2000/CSiBridge models, coincides with the one defined through Section Cutter; while for ETABS models with the corresponding “Pier/Spandrel” label. A wall is made up by a set of associated “Section Cuts” organized by appropriate labels.

Managing the walls and the related sections through the graphical interface is rather easy:

- to select a certain wall click on the corresponding check box in the navigation tab;
- to navigate through the sections click on the “Wall” tab and use the dedicated tree view in the left part of the screen. A single click select the corresponding section and the related geometry, local axes and reinforcing are shown in the center of the screen.



Within the “Wall” tab there are also some dedicated tools to customize the section reinforcing however, this is not the main purpose of this tab neither the recommended workflow. There are indeed other interactive and more productive tools, like the reinforcing editor, that allow for a detailed customization of the reinforcing of entire walls in fewer simple steps. All the different options are comprehensively described in 3.6.5. The “Wall” tab represents instead the primary tool to identify the internal layout of a certain wall and the related sections providing a prompt and exhaustive control over the model.

Given the above, the editing tools are available through the “Wall tools – Reinforcing” tab that appears in the ribbon menu when the “Wall” tab is selected. The available commands vary from the possibility to quickly assign a parametric

reinforcing to the current section to the possibility to customize in detail the reinforcing of the single legs.

3.2.5. Properties tab

The properties tab shows detailed tabular information on the current selection. If the current selection includes more than one element, the table reports the number of objects currently selected for each category (joints, beams, columns, piers and spandrels). When the current selection includes only one element, the table shows detailed information on it:

- for a single joint element the general and reinforcing properties are displayed;
- for a single frame element the general properties are reported along with the geometrical and commercial properties of the current segment;
- for a single wall element the general properties are reported along with the geometrical (to show the subsection details click on the corresponding cell of the table) and commercial properties of the current section.

3.3. The “Application” menu


From the Application menu, identified by the  button, the user can:

- start a new model;
- open an existing model;
- save the model in use;
- export input and output data to Excel or XML files, already formatted for use on calculation reports;
- import the reinforcing of selected beams, columns and walls from an existing VIS file;
- check for program updates;
- access user, design and verification manuals;
- find information on program version and license;
- select options such as language (English or Italian) and use of multithreading.

3.4. The “General Settings” Ribbon Tab

This tab allows the user to choose the reference Code and to set general parameters, typically Code related. The tab includes the following groups of commands:

- Code selection
- General design settings;
- Seismic design settings;
- Serviceability design settings.



3.4.1. Code Selection

Presently implemented Codes are:

- EC2-2005 / EC8-2005;
- Italian NTC 2018 and related commentary;
- Italian NTC 2008 and related commentary.

For each code it is also possible to activate the “Seismic” option, in order to enforce the specific design and detailing requirements prescribed for structures in seismic areas. (Ref. Chapter 7 of NTC2008 and Chapter 5 of EC8). If the box is left unchecked, the requirements will be ignored by the program.

3.4.2. General design parameters

Use this tab to specify strength design settings to be used in the calculations. Default values for most of the design settings are preset by the program, based on the code of choice and generally accepted standards; however, they can be overwritten by the user, as required.

The “General” tab includes:

- Partial γ factors for materials: these are the Eurocodes or NTC concrete and steel material partial factors.

- Concrete strength conversion: specify the conversion factor from cube to cylinder concrete strength. The default is 0.83. Alternatively select automatic conversion in accordance with EN 206-1. This command is active only when the Italian code is selected.
- Steel target strain: specify the steel target strain for bending design of concrete beams. Note that this assignment applies to all rebars in the model. This target strain is used to make univocal the solution for double reinforced concrete beams. The default value of 0.005 is recommended for adequate beam ductile behavior.
- Wall design settings: including the reinforcing cover, the preferred angle for potential inclined reinforcing, the maximum longitudinal reinforcing ratio and the preferences related to the design of non-critical sections.

The screenshot shows the 'Code preferences' dialog box with the 'General' tab selected. The settings are as follows:


- Partial factor γ for materials:**
 - Concrete: γ_c = 1.5
 - Steel: γ_s = 1.15
- Cube to cylinder strength conversion:**
 - ☐ UNI EN 206-1
 - ☒ User ratio: 0.83
- Steel target strain for beam design:**
 - ϵ_s = 0.005
- Wall design settings:**
 - Cover: 0.04
 - Maximum allowed reinforcing ratio: 4 %
 - Inclination of diagonal reinforcing: 45
- Design procedure for non-critical sections:**
 - ☒ Uniform reinforcing
 - ☐ Reinforcing prevailing at ends
 - Minimum reinforcing ratio at ends: 0.2 %

Buttons: OK, Cancel


The "Bending" tab includes:

- Maximum allowable strain: material ultimate strain values for reinforced concrete strength calculations.
- Stress distribution assumption: either stress block or rectangle-parabola stress distribution. Note: the stress block method is faster; however, the rectangle-parabola method is more accurate in case of sections not doubly-symmetric.
- Stress parameters: assign the stress reduction factor α (long-term effects and unfavorable loading) and the stress block factor β (block height reduction). Note: some codes recommend using different α values depending upon the geometry of the concrete section, whether the width increases or decreases


starting from the compression face. This criterion cannot be applied to a complex model having different concrete sections and load combinations, and therefore it is generally recommended that the default (most conservative) value is used.



The “Shear” tab allows to customize the shear strength mechanism. For those Codes using the variable angle Strut and Tie model, the strut inclination can be preset by user or calculated by the program. EC2-2005 and NTC2018/2008 allow a strut and tie model with variable inclination, where: $1 \leq \cot(\theta) \leq 2.5$. The program-calculated inclination is optimized at each location based on current reinforcing and code requirements. If the user assigns a preset inclination, this remains fixed at all locations.




Within the “Imperfections” tab it is possible to specify the value of the basic imperfection factor and other parameters which influence its value. If the effects of imperfections have already been included in the analysis, it is possible to avoid the calculation of additional moments by flagging the option “Already included in analysis”.



Within the “Second order” tab it is possible to specify the type of analysis that have been run choosing between three different options:

- 1st order – select this option if only linear analysis have been run. Second order effects will be added to the moments using the effective length method.
- 2nd order with P-Δ effects – select this option if non linear analysis considering global second order effects have been run. Local second order effects will be added to the analysis moments using the effective lengths lower or equal to 1.
- 2nd order with P-Δ and P-δ effects – select this option if non linear analysis considering both global and local second order effects have been run. Analysis moments will not be further incremented.

If the analysis is “1st order” or “2nd order with P-Δ effects” the user has the option to customize the parameters involved in the calculation of the second order effects.



3.4.3. Seismic design parameters

This group of commands is used to enter Code parameters required to define structures in seismic zones. The commands are code sensitive.

- Structural properties: select the structural behavior (dissipative or non-dissipative) and the corresponding ductility class. Eurocodes Low ductility class prescriptions are met leaving the seismic zone box unchecked.
- Shear wall capacity design: set the parameters related to the capacity design of primary seismic walls (behavior factor to be used in the shear magnification, the

related spectral accelerations and the if the structure is a Dual System structure).

- Curvature ductility: enter this text box to specify the curvature ductility factors for local axes 2 and 3. These factors are used to check column confinement provisions on critical regions in accordance with EC8-2005 - paragraph 5.2.3.2 and paragraph 5.2.3.4.
- Capacity design of joints: select the approach for the shear capacity design of concrete beam-column joints.
- Beam-column PMM capacity design: select how to distribute the longitudinal design reinforcing between the bottom and top column of a selected joint (for additional details see 3.9.1).

3.4.4. Serviceability design Settings

This group of commands is used to enter Code parameters pertaining to serviceability limit states design (Stress Limitation and Crack Control). The commands are code sensitive.

Default values are preset by program based on conservative use of code provisions and generally accepted standards.


- Es/Ec: enter this text box to specify the modular ratio of steel to concrete, for Stress Limitation design.
- Crack control: (EC2 2005) - enter this pull down menu to specify the limit state of concern for crack control design (Decompression, Crack formation or Crack width).
- Wlim: (EC2 2005) - this text box is used to specify the maximum allowable width (mm) of cracks if the limit state is crack width.

- k1: (EC2 2005) - this text box is used to specify the reduction coefficient to be applied to concrete characteristic strength for Stress Limitation design with characteristic load combinations.
- k2: (EC2 2005) - this text box specifies the reduction coefficient to be applied to concrete characteristic strength for Stress Limitation design with quasi-permanent load combinations.
- k3: (EC2 2005) - this text box is used to specify the reduction coefficient to be applied to steel characteristic yield strength for Stress Limitation design with characteristic load combinations.
- Crack Conditions: (NTC 2008) enter this pulldown menu to specify the environmental condition limit state of concern for crack control design (Ordinary, Aggressive, Highly aggressive)
- Crack Reinforcing: (NTC 2008) enter this pulldown menu to specify the type of reinforcing in use for crack control design (Slightly sensitive, Sensitive).

3.5. The “Define” Ribbon Tab

The commands from this tab are used to define or modify default materials, objects, components, internal forces, and groups.

Each button opens a dedicated window. Some have pull down lists of commands for specific members or components.



3.5.1. Default Materials

This group of commands is used to set the default materials to be assigned to new elements and to view the material properties.

It is important to note that the materials selected here will be assigned by default to all elements defined thereafter, but will not affect existing elements. To change the material properties of existing elements use the command “Edit > Concrete”, or “Edit > Steel”, after the elements are selected.

Also, note that elements imported from SAP2000 inherit the material properties defined there.


Concrete

Typically, concrete is defined by selecting a concrete class. However, user defined concrete can be assigned based on strength: cylinder or cube. (For those countries where cube strength is used, the conversion factor from cube to cylinder strength can be defined from the “General Settings” ribbon).

- Class: specify the Concrete Class to be assigned to all new members. This assignment does not affect previously defined or imported members. To modify the Concrete class of previously defined and imported members, use the command “Edit > Concrete > Class”.
- Concrete strength: if the class specified above is “user”, assign here the desired strength.

Note that the command is sensitive to the code in use: strength here is cylinder strength fck for Eurocodes and cube strength Rck for NTC.

Details on concrete properties can be obtained by clicking on the "Property details" button, at the bottom right side of this group. This will provide the design values of strength and other mechanical properties associated with the selected concrete class. The properties depend upon the design Code currently in use. This information is useful to understand the parameters used by VIS during the design process.



A screenshot of a software dialog box titled "Concrete properties". It contains a table of mechanical properties for concrete. The table has three columns: the property name, the symbol used, and the numerical value. The properties listed are: Characteristic cube strength (Rck = 30), Characteristic cylinder strength (fck = 24.9), Design cylinder strength (fcd = 14.11), Characteristic axial tensile strength (fctk = 1.791), Design axial tensile strength (fctd = 1.194), Modulus of elasticity (E = 3.145e+04), Mean tensile strength (fctm = 2.558), Mean cylinder strength (fcm = 32.9), and Mean elastic modulus (Ecm = 3.145e+04). There is an "OK" button at the bottom right of the dialog box.

Property	Symbol	Value
Characteristic cube strength	Rck =	30
Characteristic cylinder strength	fck =	24.9
Design cylinder strength	fcd =	14.11
Characteristic axial tensile strength	fctk =	1.791
Design axial tensile strength	fctd =	1.194
Modulus of elasticity	E =	3.145e+04
Mean tensile strength	fctm =	2.558
Mean cylinder strength	fcm =	32.9
Mean elastic modulus	Ecm =	3.145e+04

Steel


These commands can be used to define the steel properties to be assigned to all reinforcing steel, modeled thereafter. Typically, these properties are defined selecting a steel grade. User defined steel can be assigned as well, based on yield stress.

- Grade: specify the steel grade to be assigned to all new reinforcing from a drop down list.

Note that this assignment does not affect previously inserted rebar, including those imported from the SAP model. To modify the steel grade of previously inserted rebar, use the command "Edit > Steel > Grade".

- fyk: if steel is user defined, specify the yield stress to be assigned to all new reinforcing here.

Details on steel properties can be obtained by clicking the "Property details" button, at the bottom right side of this group of commands. This will provide design values of the mechanical properties of the selected steel grade. The properties are those used by the program during the design process and depend upon the design Code currently selected.



3.5.2. Objects

This group includes the definition of several design objects and their properties. Precisely: Joints, Sections, Frames, and Walls.

Typically, objects imported from SAP2000 already have their properties assigned. Consequently, VIS does not have property assigning commands. In the (rare) case when new objects are defined, all their properties are assigned during the object definition. Properties can later be modified using the edit commands.

Joints

Use this button to:

- add joints to the model;
- rename joints;
- modify joint locations (this applies only to user defined joints, not to joints imported from SAP2000).

Sections

From this button, access a dedicated window used to define or edit Frame Sections. Editing here is global. In other words, a change applied to a given section is applied to all segments using a section with that name within the entire model. The available operations are:

- Define
- Modify
- Replicate
- Delete
- Substitute

Note that, after they are defined, sections can be rotated by applying a rotation to the corresponding frame element (like it is possible in SAP/CSiBridge/ETABS). In this way the variety of available types becomes much larger.

To define a new section, first select a section type clicking on a suitable icon. This opens a dedicated window for the parametric input of section data. The section types are Generic, Rectangular, T section, L section, Circular

To define a generic section, the user is required to provide the cartesian (x,y) coordinates of all vertexes and rebar. Any shape of section and number of vertexes are accepted and multiple holes can also be defined. The input for all other section types is much simpler, since only a few parameters are required.

When defining/editing a section, the related reinforcing can also be created. Dedicated commands for the parametric definition of longitudinal and transverse reinforcing are present for each shape and, for a detailed customization of the layout, it is possible to access a more general reinforcing definition window (simple click on the edit button in the lower left part of the section draw).

Shear design is implemented for all shapes but for generic sections the related equivalent dimensions should be manually specified. The values of effective longitudinal tensile reinforcing for the shear check of unreinforced elements ($Asl2$ and $Asl3$) should be manually defined by the user (the default value is 0).

To substitute a section with a different one, drag its icon and drop it over the other. Drag and drop is allowed only for sections belonging to the same type.

Rectangular section definition [X]

Section name: COL30x60

☒ Enable shear check
☐ Define parametric reinforcing

Section geometry


b: 0.3
h: 0.6

Stirrups/ties data

No. of legs in 3-dir: 2
No. of legs in 2-dir: 2
Diameter: 0.0127
Spacing: 0.15
 α : 90
Fyw: 4.5e+08
Asl 3-dir: 0
Asl 2-dir: 0

Longitudinal reinforcing data

No. of horizontal rebars: []
No. of vertical rebars: []
Rebar diameter: d 20
Cover to center of rebar: 0.0627




OK Cancel

Frames

From this button, access the frame manager window. This window is used to define or edit frame elements within the current model. The list of all columns and beams is reported in two separate tabs. Selecting any of these elements provides easy access to each for editing and other operations. For each element selected, the following commands are available:


- Define: to define a new column or beam;
- Edit: to open the edit window for the selected element;
- Convert: to convert a column into a beam or a beam into a column;
- Forces: to open the Internal Forces input table for the selected element;
- Delete: to delete the selected element.



The cancel button allows undoing any of these operations.

The “Define” button (as well as the Edit button) from the “Frame Manager” opens the element definition window.

The column definition window is as follows.



-
- Name: column ID.
 - Rotation: this text box can be used to assign a rotation to the column section, (as in SAP). The default is zero.
 - i and J joints: the start and end joints of a column.
 - Section Type: these buttons filter the list of available sections,
 - Concrete fck: this text box overwrites the default concrete (cylinder) strength for this member. If the model is imported from SAP, the strength is derived from the SAP model. For new elements, the strength is that from the "Default Materials" command group, found in this tab.
 - K factors: this text box allows overwriting of the column K factors defining the column's effective length along the section major and minor axes. The default value is auto, which means that the effective length factors will be calculated by the program.
 - Seismic bending: a dropdown list to allow the selection of column bending behavior, either single or double curvature. This behavior cannot be obtained from a response spectrum analysis, because of the indeterminate sign of results; however, the information is necessary for column slenderness calculations. When slenderness calculations are relevant, the user should look at the deformed shape of the first modes or that of an equivalent static analysis to evaluate the type of curvature to be expected.
 - Modify segments: this section is used to subdivide the column into separate "uniform reinforcing" segments and assign to each its own section, chosen from a list.
 - Insertion mode: the segment insertion mode, whether relative or absolute. If relative, simply input the desired number of equally spaced segments. If absolute, enter the length of each segment.
 - Section: a dropdown list with the model's current column sections to be assigned to each segment. If desired, click the "Create..." button to define a new section after having selected section type first.
 - Number: the number of segments required. Click the "Subdivide" button to generate equal length segments.
 - Segments: enter this data table to edit section assignment or the length of each segment previously defined.
 - Column length: calculated by the program and based on end joint location.
 - Note: for proper design of slender columns, the columns imported from SAP need to include only a single frame element.

The beam definition window is as follows.

	Section	Length	Relative length
1	R30x50-8	0.8	16.00%
2	R30x50-11	0.6	12.00%
3	R30x50-2	2.2	44.00%
4	R30x50-11	0.6	12.00%
5	R30x50-8	0.8	16.00%

- Name: beam ID;
- Rotation: this text box can be used to assign a rotation to the beam section (as in SAP). The default is zero.
- Concrete fck: this text box overwrites the default concrete (cylinder) strength for this member. If the model is imported from SAP, the strength is derived from the SAP model. For new elements, the strength is that from the "Default Materials" command group found in this tab.
- i and j joints: the start and end joints of the beam.
- Section Type: these buttons filter the available section types.
- Modify segments: this section is used to subdivide the beam into separate "uniform reinforcing" segments and assign to each a section, chosen from a list.
- Insertion mode: the segment insertion mode, whether relative or absolute. If relative, simply input the desired number of equally spaced segments. If absolute, enter the length of each segment.
- Section: a dropdown list with available sections to be assigned to each segment. If desired, click the "Create..." button to define a new section after having selected a section type, first.
- Beam span: overall beam length calculated by the program and based on end joints.
- Number: number of segments required. Click the "Subdivide" button to generate equal length segments.

- Segments: data table to edit section assignments or length of segments previously defined.


Walls properties

From this button, access the walls manager window. This window is used to edit wall elements within the current model. The list of all piers and spandrels is reported in two separate tabs. Selecting any of these elements provides easy access to each for editing and other operations. For each element selected, the following commands are available:

- Edit: to open the edit window for the selected element;
- Forces: to open the Internal Forces input table for the selected element;
- Delete: to delete the selected element.

In addition, for pier type walls, the following additional commands are present:

- Critical zone: allows to define the critical zone extension of the selected walls by specifying the limiting elevation or the total extension from the base;
- Seismic type: allows to define if the selected walls should be designed as ductile walls or large lightly reinforced walls.



The "Edit" button from the "Walls Manager" opens the element definition window.

The pier definition window is as follows.

Wall WALL-X-1

Type: **Pier (Vertical Wall)** ☐ Large lightly reinforced Base storey height 3.00 m

Wall is slender Total height 18.00 m Critical region height 3.00 m

☒ Consider out of plane shear K maj: 1 K min: 0.1667

Section	Number of legs	Section elevation	fck	Critical	Use transverse reinforcement
3B	1	3	2.5e+04	<input checked="" type="checkbox"/>	<input type="checkbox"/>
3T	1	6	2.5e+04	<input checked="" type="checkbox"/>	<input type="checkbox"/>
4B	1	6	2.5e+04	<input checked="" type="checkbox"/>	<input type="checkbox"/>
4T	1	9	2.5e+04	<input type="checkbox"/>	<input type="checkbox"/>
5B	1	9	2.5e+04	<input type="checkbox"/>	<input type="checkbox"/>
5T	1	12	2.5e+04	<input type="checkbox"/>	<input type="checkbox"/>
6B	1	12	2.5e+04	<input type="checkbox"/>	<input type="checkbox"/>
6T	1	15	2.5e+04	<input type="checkbox"/>	<input type="checkbox"/>
7B	1	15	2.5e+04	<input type="checkbox"/>	<input type="checkbox"/>
7T	1	18	2.5e+04	<input type="checkbox"/>	<input type="checkbox"/>
8B	1	18	2.5e+04	<input type="checkbox"/>	<input type="checkbox"/>
8T	1	21	2.5e+04	<input type="checkbox"/>	<input type="checkbox"/>

OK Cancel

- **Name:** the name of the pier is reported on the title of the window;
- **Wall type:** pier;
- **Large lightly reinforced:** defines if the pier should be designed as large lightly reinforced wall as defined by the design code selected. This option is active only when the seismic option is active and the design code is set to EC or NTC;
- **Slenderness:** defines if the wall is slender ($h/l > 2$) or squat with reference to the seismic behavior;
- **Consider out of plane shear:** this option activates or deactivates the shear check in the transverse direction of each leg which sometimes, especially in the case of composite wall stacks, can underestimate the true strength due to the presence of high tensile forces;
- **Second order (K factors):** effective length factors along the two principal directions. For simple walls the default value is 1 in the major direction and h/h_1 in the minor direction, where h is the total height of the wall and h_1 is the height or the first story. For composite wall stacks the default value is 1 in both directions.
- **Total height:** the total height of the wall measured from the lowest to the higher section cut;
- **Base story height:** distance between the first two section cuts, used for the calculation of the default critical region height according to the selected code;
- **Critical region height:** default value of the critical region height calculated according to the selected code. This value can be easily overwritten by editing the "Critical" column in the sections table;

- **Sections table:** summary table which reports the following basic property of the different sections of the pier;
- **Section:** name of the section cut;
- **Number of legs:** number of legs of the section;
- **Elevation:** elevation of the section measured in the global coordinate system;
- **Rck/fck:** cube or cylinder strength of the concrete of the section;
- **Critical:** indicates if the section is inside the critical region. All the sections below the highest critical sections are automatically flagged as critical;
- **Use transverse reinforcement:** defines the strength mechanism for the shear check in the transverse direction for simple walls. By default, the shear strength in the transverse direction is calculated as for unreinforced members. To consider the contribution of transverse ties users should check this option.

The spandrel definition window is as follows.

Section	Number of legs	Section location	fck	
1	1	0	2.5e+07	
2	1	1.5	2.5e+07	
3	1	3	2.5e+07	

- **Name:** the name of the spandrel is reported on the title of the window;
- **Wall type:** spandrel;
- **Slenderness:** defines if the spandrel is slender ($h/l > 2$) or squat with reference to the seismic behavior;
- **Total length:** the total length of the wall measured from the nearest to the farthest section cut;
- **Sections table:** summary table which reports the following basic property of the different sections of the spandrel;
- **Section:** name of the section cut;
- **Number of legs:** number of legs of the section;

- **Station location:** distance of the section from the origin of the spandrel;
- **Rck/fck:** cube or cylinder strength of the concrete of the section.

3.5.3. Internal Forces

The command "Display" allows to review the internal forces for a selected element. A single frame or wall element needs to be selected first.

Each set of internal forces shown on the "Frame Internal Forces" window refers to a separate station along the frame element and to a separate load combination or permutation. These sets of forces are grouped by segment: one group for each frame segment.

Internal force sets are typically imported from SAP2000. However, they can be edited or defined directly by the user. Copy and paste is permitted. It is mandatory for the station coordinate to fall within the segment to which it belongs.

The forces are also organized according to the Limit State of each combination. Precisely:

ULS: Ultimate Limit States - Fundamental and Seismic load combinations. The Seismic combination is identified by a check box in the "Seismic" column. If the check box is active, the load combination is considered by the program as a Seismic Life Saving load combination. If the box is unchecked, the combination is considered as a fundamental Ultimate Limit State combination, not seismic.

CHR/SLS: Serviceability Limit States - Rare load combinations.


FRQ/SLS: Serviceability Limit States - Frequent load combinations.

QPR/SLS: Serviceability Limit States - Quasi-permanent load combinations.

Data are organized into a spreadsheet where each row refers to a set of forces. The columns have the following headings and meanings:

- Station: station location referred to frame origin (i node).
- Combination: load combination name.
- Type: the sign of results from a response spectrum analysis is indeterminate. For each seismic load condition, eight permutations are obtained alternating positive and negative signs and combining the forces with those from other load conditions. Permutations are identified here by a number from 1 to 8. Design checks are run separately for each.
- $N_d, M_{3d}, \dots, V_{2d}$: Internal forces, one set for each station and load condition.

- Seismic: check box for ULS combinations. When checked the combination is to be treated as seismic Life Saving ULS, if unchecked as non-seismic fundamental ULS.




Internal Forces

Frame: 156 Segment: 1 Limit state: SLU/SLV

Station	Combination	Type	Nd	M3,d	M2,d	V3,d	V2,d	Seismic
0.25	STR19	Simple	-141.71	9.5214	52.049	48.806	9.3033	<input type="checkbox"/>
0.25	STR20	Simple	-144.11	9.1004	49.746	48.181	8.937	<input type="checkbox"/>
0.25	STR21	Simple	-144.02	9.296	49.692	48.132	9.1109	<input type="checkbox"/>
0.25	STR22	Simple	-143.55	9.3456	52.44	49.401	9.1569	<input type="checkbox"/>
0.25	STR23	Simple	-143.46	9.5412	52.386	49.352	9.3308	<input type="checkbox"/>
0.25	QKE1	Permutation #1	-103.57	-18.773	17.723	16.368	-16.439	<input checked="" type="checkbox"/>
0.25	QKE1	Permutation #2	-103.57	-18.773	40.158	16.368	21.157	<input checked="" type="checkbox"/>
0.25	QKE1	Permutation #3	-103.57	23.114	17.723	38.618	-16.439	<input checked="" type="checkbox"/>
0.25	QKE1	Permutation #4	-103.57	23.114	40.158	38.618	21.157	<input checked="" type="checkbox"/>

OK Cancel

The “Wall Internal Forces” window is organized according to the wall section cuts. On the left side, the navigation bar allows the user to move between the various section cuts of the wall. On the right side, the internal forces for the selected section are organized in a spreadsheet format.




Wall forces

SET10X2

	Combination	Seismic	Type	N	M3	M2	V3	V2
9	STR9	<input type="checkbox"/>	Simple	-672.8	-2.614	-15.85	39.2	-2.086
10	STR10	<input type="checkbox"/>	Simple	-679	-2.589	-16.79	40.14	-2.074
11	STR11	<input type="checkbox"/>	Simple	-794.6	-2.751	-17.79	47.38	-2.165
12	STR12	<input type="checkbox"/>	Simple	-800.8	-2.726	-18.72	48.32	-2.153
13	STR13	<input type="checkbox"/>	Simple	-760.8	-2.691	-17.8	45.49	-2.132
14	STR14	<input type="checkbox"/>	Simple	-754.6	-2.675	-17.81	45.29	-2.123
15	STR15	<input type="checkbox"/>	Simple	-789.3	-2.723	-18.11	47.47	-2.15
16	STR16	<input type="checkbox"/>	Simple	-762.7	-2.683	-18.08	45.77	-2.128
17	STR17	<input type="checkbox"/>	Simple	-797.3	-2.732	-18.38	47.94	-2.156
18	STR18	<input type="checkbox"/>	Simple	-791.1	-2.716	-18.39	47.75	-2.147
19	STR19	<input type="checkbox"/>	Simple	-799.2	-2.724	-18.66	48.22	-2.152
20	STR20	<input type="checkbox"/>	Simple	-762.4	-2.693	-17.86	45.58	-2.133
21	STR21	<input type="checkbox"/>	Simple	-764.3	-2.685	-18.14	45.86	-2.129
22	STR22	<input type="checkbox"/>	Simple	-798.9	-2.734	-18.44	48.04	-2.157
23	STR23	<input type="checkbox"/>	Simple	-800.8	-2.726	-18.72	48.32	-2.153
24	QKE1	<input checked="" type="checkbox"/>	Permutation #1	-1107	-4.795	-159.3	-20.6	-4.415
25	QKE1	<input checked="" type="checkbox"/>	Permutation #2	-1107	0.5356	-159.3	79.59	-4.415
26	QKE1	<input checked="" type="checkbox"/>	Permutation #3	-1107	-4.795	125	-20.6	1.027
27	QKE1	<input checked="" type="checkbox"/>	Permutation #4	-1107	0.5356	125	79.59	1.027
28	QKE1	<input checked="" type="checkbox"/>	Permutation #5	70.91	-4.795	-159.3	-20.6	-4.415


Show diagram

Click on the “Show diagram” button, on the lower left side of the window, to see the internal force diagrams for each load combination or for their envelope.



The “Redistribute” command allows *Moment Redistribution* to be applied to the bending moments of selected beams in accordance with the code of preference. The redistribution affects ULS bending moments from non-seismic design situations. It is applied to active selections only. If no selection is active, the redistribution is applied to all beams in the model.

The user can specify the amount of moment redistribution to be applied as a percentage of the code maximum allowed. To do so, click on the “Advanced” button from the tab “Define”, group “Internal forces”.




This operation is non additive. In other words, if the redistribution is applied more than once, it will always start again from the original moments imported from the analysis. Hence, to delete any redistribution, simply apply a new redistribution where the applied percentage is null.

3.5.4. Groups

These commands are used to define groups of objects. The groups are used to facilitate selection at a later time and are made available from the navigation bar from the main window. To define a group, simply select the desired objects, write a name for the group, and click the “Create” button. Groups can eventually be deleted with the “Delete” button.

3.6. The “Edit” Ribbon Tab

The commands from this tab can only be used after one or more elements are selected.



3.6.1. Concrete and Steel

Material properties are typically inherited from the SAP model or assigned to each element from the default material definition.

However, materials assigned to each element can be overwritten using the edit command from this ribbon tab, after one or more elements (beam, column or wall) are selected. The user can choose a predefined concrete class or steel grade or define them directly.

This overwrite is assigned by clicking the apply button.

3.6.2. Slenderness Factor

This group of commands can be used to overwrite the slenderness factor K for one or more selected columns or wall piers. Slenderness factors are used for slender column design and need to be assigned for both principal directions.

3.6.3. Seismic Bending

This group of commands can be used to overwrite the seismic bending behavior for one or more selected columns or wall, the choice being between single or double curvature. By default, columns imported from the SAP model are assigned a single curvature bending behavior (which is the most conservative assumption). The column bending behavior cannot be obtained from a response spectrum analysis, because of the undetermined sign of results; however, the information is necessary for column slenderness calculations.

3.6.4. Segments

This group of commands has been specifically designed to give users all the necessary tools to assign/edit the reinforcing of frame elements. The main possible workflows are essentially two:

- manual subdivision of frame elements into a certain number of segments (“Split frames” command) and subsequent assignment of previously defined sections to each segment (“Assign sections” command). In this way it is possible to fully customize the internal structure of the selected frame elements and control the sections assignments.
- Interactive definition and/or editing of reinforcing of entire beam rows or column rows (“Edit reinforcing” command). Using this approach it is possible to revise and modify both the longitudinal and transverse reinforcing of entire lines of beams/columns defining the position of each bar across the section and the corresponding extension. Users will not need to manually define the segments and the corresponding sections as the software will automatically create the internal subdivision of each frame basing on the defined reinforcing layout. Within the same environment it is also possible to update all the checks in real time and evaluate the effect of the applied changes.

The two workflows introduced above are independent and the choice of which one to follow is essentially problem dependent: in certain cases the manual subdivision and assignment strategy is more effective, like for example in buildings with several modular elements (precast structures); in others the interactive editing is more productive, especially for continuous beam rows with variable reinforcing.

Going into the details of the single commands, the function “Split frames” allow to internally subdivide the selected frames into a set of segments of variable length. It is possible to use a parametric subdivision, which allows for the quick creation of a certain number of segments, or a manual subdivision which allows for a detailed subdivision.

Divide frames

Number of segments

5

End segments length

☒ Critical length

Mid segment length

1

OK Cancel Advanced...

Divide frames

Number of segments

5

End segments length

☒ Critical length

Mid segment length

1

OK Cancel Advanced...

☐ Absolute values ☒ Relative values

Segment	Length
1	10
2	15
3	50
4	15
5	10

The “Assign sections” command allows to assign the desired section to the different segments of the selected frames. If the current selection includes elements with a different number of segments, the assign window will include a number of rows equal to the maximum number of segments in the selected elements.

Assign sections



Section type

Segment Section

1	R30x50-1
2	R30x50-2
3	R30x50-1

OK Cancel


The third, and last, command “Edit reinforcing” opens an interactive environment where the reinforcing of a selected line of beams or columns can be edited with extreme precision. For the command to be active, first select a frame element. The entire line, to which the selected element belongs, will be made available for editing.



The editing environment includes five separate areas:

1. Section area – This area displays the section of the selected column or beam. The section is cut at the present location of the Slider Bar on the elevation area. Click on the edit button, to edit both longitudinal and transverse reinforcing.

The change applies to the rebars belonging to the segment of reinforcing where the slider is positioned. If a selection from the Elevation Area is active, the change applies to all selected stretches of reinforcing (some restrictions apply).



2. Elevation area – The entire reinforcing belonging to the selected line of beams or columns is shown in detail. Either the longitudinal or the transversal reinforcing can be selected, by choosing the corresponding tab at the bottom of the window. A click of the mouse can be used to select a given portion of reinforcing. The dimensions of the selected reinforcing are shown in the dimension area. Press “Esc” to exit the selection. A right click on a certain longitudinal reinforcing line will open a dedicated window which allows for a quick variation of the number and diameter of the selected rebars. A diameter change is always possible while the variation of the number of rebars depends on the number of different diameters currently assigned to the frame row. VIS can handle the automatic redistribution of up to two different diameters. If the current number of diameters assigned is more than 2, the changes should be applied manually by defining the rebar location in the section area and drawing the extension in the dimension area.
3. Dimension area – This area shows location and dimension of homogeneous stretches of reinforcing, to be edited. These stretches include one or more rebars that are homogeneous in length, spacing and size. First you need to select the rebars to be edited (from either the Elevation or the Section areas). Selection from the Elevation area will engage all homogeneous reinforcing at once. Selection from the Section area allows for engagement or disengagement of single rebars. **Note that the dimensions shown refer to the effective calculation length. They do not include anchorage or splices.**
 - To modify the extent of longitudinal or transversal reinforcing drag the grips at the end of each stretch of reinforcing. If two separate stretches touch, they become a single stretch.

- To create new rebars point at the desired location for the new stretch and left click at the beginning and the end. Helpful snaps are prearranged for this purpose. Alternatively use the mouse to select the starting point and direction and assign the length numerically, after pressing the “Tab” button.
 - To delete a stretch, select it with a left click of the mouse and press the “Canc” button.
 - Press “Esc” to exit the present stretch selection.
4. Design checks area – This area shows the summary of results for all checks run on the frame element, at the location of the slider bar. The results are reported as D/C ratios for each Limit State. To open the detailed result window for a given Limit State, click on the desired Limit State summary report. Results are automatically deleted as soon as any change occurs in the reinforcing layout. To update the results click on the “Check” button in the section area.
5. Color coded results line – This area is a color-coded graphic display of the results for the entire line of columns or beams. The results refer to limit state selected from the Design Checks area. If more than one limit state is selected, the color will correspond to the highest D/C among the selected.

3.6.5. Walls reinforcing

This group of commands has been specifically designed to give users all the necessary tools to assign/edit the reinforcing of wall elements. The main possible workflows are essentially two:

- parametric reinforcing assignment to a selection of wall piers or spandrels (“Piers” or “Spandrels” command). In this way it is possible to define the full reinforcing to be assigned to certain sections of the current selection of wall elements. The command window will allow to select the elevation range (in the case of piers) or station range (in the case of spandrels) to which the reinforcing should be assigned.
- Interactive definition and/or editing of reinforcing of an entire wall (“Edit reinforcing” command). Using this approach it is possible to revise and modify both the longitudinal, transverse and diagonal reinforcing of entire walls. Dedicated commands to copy the reinforcing among different levels are also present. Within the same environment it is also possible to update all the checks in real time and evaluate the effect of the applied changes.

The two workflows introduced above are independent and the choice of which one to follow is essentially problem dependent: in certain cases the manual assignment strategy on more walls at a time is more effective, like for example in buildings with

several large walls with constant reinforcing; in others the interactive editing is more productive, especially for complex wall stacks with seismic detailing.

Going into the details of the single commands, the functions “Piers” and “Spandrels” reinforcing allow to assign a parametric reinforcing to the current selection of elements. It is possible to specify the elevation or station range on which the assignment will be performed in order to allow for an easier variation over the height/length of the member. For pier type walls the input parameters are:

- elevation range over which the reinforcing is to be applied;
- cover;
- yield stress of reinforcing bars;
- number, diameter and spacing of longitudinal bars at ends and intersections. Leaving the default “auto” spacing the rebars will be placed at a distance equal to the thickness minus two times the cover;
- diameter and spacing of the longitudinal bars in the internal regions;
- diameter and spacing of shear reinforcing;
- number of legs, diameter and spacing of transverse ties.

Parametric reinforcement assignment

Elevations
From 0 To 6

General parameters
Cover 0.05 Fyk 4.5e+05

Vertical reinforcement
Reinforcement at ends and intersections
End rebars 8
Diameter d 20 Spacing auto

Internal region
Diameter d 12 Spacing 0.2

Horizontal reinforcement
Diameter d 10 Spacing 0.2

Transverse reinforcement at ends and intersections
Cross ties 4
Diameter d 6 Spacing 0.1

OK Cancel

For spandrel type walls the input parameters are:

- station range over which the reinforcing is to be applied;
- cover;
- yield stress of reinforcing bars;
- number, diameter and spacing of longitudinal bars at ends and intersections.
Leaving the default “auto” spacing the rebars will be placed at a distance equal to the thickness minus two times the cover;
- diameter and spacing of the longitudinal bars in the internal regions;
- diameter and spacing of shear reinforcing;
- number of legs, diameter and spacing of transverse ties.

Parametric reinforcement assignment

Stations
From 0 To 3

General parameters
Cover 0.05 Fyk 4.5e+05

Vertical reinforcement
Reinforcement at ends and intersections
End rebars 2
Diameter d 16 Spacing auto


Internal region
Diameter d 8 Spacing 0.1

Horizontal reinforcement
Diameter d 8 Spacing 0.1

Transverse reinforcement at ends and intersections
Cross ties 0
Diameter d 6 Spacing 0.2

OK Cancel

The third, and last, command “Edit reinforcing” opens an interactive environment where the reinforcing of a selected wall can be edited with extreme precision. For the command to be active, first select a wall element.



The editing environment includes five separate areas:

1. Section area – This area displays the section currently selected, if unique. If the current selection includes more than one section, or none, the area will remain empty. When a valid selection is active, this area provides a direct interaction with the reinforcing allowing for the selection of rebars and execution of the editing command available on the command panel (4).
2. Cuts list – Ordered list of all the section cuts associated to the current wall. Click to select a certain section and view it in the section area. To select more than one section, useful for example to paste a reference reinforcing to more sections in one session, hold the Ctrl button.
3. 3D view box – In this area all the sections associated to the current wall are displayed in the model space. Possible overlapping sections (sections at the same elevation) are offset by a specified amount that can be set in the command panel. Sections can be selected with a simple click or with a rubber band selection. Zoom and pan operations can be performed exactly like in the main window of the program. When checks results are present, it is possible to plot the contours of the D/C ratios by simply checking the corresponding limit state in the checks box (5). If more than one limit state is selected, the color will correspond to the highest D/C among the selected.
4. Command panel – This panel includes all the available commands for the selected wall. The group “Global commands” allows to perform the check of the entire wall (after the reinforcing of all the sections have been defined) and to

copy and paste a certain reinforcing to other elevations/stations. At this purpose simply select the base section and click on “Copy reinforcement”. The reference section will be highlighted in red and to paste the reinforcing simply select the target sections and click on “Paste reinforcement”.

The “Reinforcement commands” group includes a set of global commands for the definition of the reinforcement of the current section. The “Parametric reinforcement” command allows for the definition of a complete parametric reinforcement with the same approach we saw previously for the manual assignment. The “Perimeter reinforcement” command allows instead for the definition of the longitudinal reinforcement along each edge of the section by specifying diameters and spacing or the total number of rebar.

Perimeter rebar assignment

Edges are numbered anticlockwise from the lower left corner.

	Use spacing	Rebars/Spacing	Diameter	Net cover	Vertex diameter
1	<input checked="" type="checkbox"/>	0.1	0.01	0.05	0.016
2	<input checked="" type="checkbox"/>	0.1	0.01	0.05	0.016
3	<input checked="" type="checkbox"/>	0.1	0.01	0.05	0.016
4	<input checked="" type="checkbox"/>	0.1	0.01	0.05	0.016
5	<input checked="" type="checkbox"/>	0.1	0.01	0.05	0.016
6	<input checked="" type="checkbox"/>	0.1	0.01	0.05	0.016
7	<input checked="" type="checkbox"/>	0.1	0.01	0.05	0.016
8	<input checked="" type="checkbox"/>	0.1	0.01	0.05	0.016

OK Cancel

The “Diagonal reinforcement” command defines the optional diagonal reinforcing of each leg.

Diagonal reinforcement definition

Leg	Area	Angle
1	1608	45
2	1608	45
3	1608	45

OK

The “Detailed reinforcement” command displays a summary window with all the reinforcement assignments of the current sections allowing for a detailed customization. It is possible to edit the table of the longitudinal rebars, to customize the shear and transverse reinforcing of each leg along with the corresponding diagonal reinforcing. When editing a certain leg click on the “Apply” button before switching to a different leg otherwise the assignments

will be lost. The “Delete reinforcement” command completely deletes the reinforcement assigned to the current section.

Detailed reinforcement assignment

General parameters

Fywk 4.6e+05

Transverse reinforcement spacing 0.1

Leg 1

Horizontal reinforcement leg #1

Rebars 2 Diameter d 10 Spacing 0.1

Transverse reinforcement leg #1

Legs 8 Diameter d 6 Asl 0

Inclined reinforcement leg #1

Area 0 Angle 45

Vertical reinforcement coordinates of entire section

3	2	Diameter	Fyk		
-3.05	2.6	0.022	5e+05		
-3.05	2.4	0.022	5e+05		
-3.15	2.6	0.022	5e+05		
-3.15	2.4	0.022	5e+05		
-3.25	2.6	0.022	5e+05		
-3.25	2.4	0.022	5e+05		
-3.35	2.6	0.022	5e+05		
-3.35	2.4	0.022	5e+05		

OK Cancel Apply

The “Rebars commands” group includes a set of dedicated commands for the local editing of the section rebars like, for example, the creation of a set of bars along the line defined by two selected rebars, the moving/replication of the selected bars, the creation of a transverse tie between two selected bars or the deletion of the selected bars. All these commands are especially useful for a detailed customization of the initial parametric distribution and allow for a higher level of detail on the rebar placing.

The “View” group allows to define the offset between overlapping sections, to show the global reference system of the wall in the 3D view box and the local axes of each leg in the section area.

5. Checks area – This area shows the summary of results for all checks run on the current section of the wall element. The results are reported as D/C ratios for each Limit State. To open the detailed result window for a given Limit State,

click on the desired Limit State summary report. Results are automatically deleted as soon as any change occurs in the reinforcing layout. To update the results click on the “Check” button in the command panel. By checking the box beside any limit state the corresponding contours of D/C ratios over the different sections will be displayed in the 3D view. If more than one limit state is selected, the color will correspond to the highest D/C among the selected.

3.6.6. Joints reinforcing

With this command the user can assign a specific shear reinforcing to a group of selected beam-column joints. If a single joint is selected, it is also possible to select whether the joint’s geometry should be calculated according to the bottom column (default option) or the top column (if present).

3.6.7. Seismic Relevance of Members


With reference to seismic design, columns and beams are considered primary or secondary members. Seismic provisions and capacity design are applied to primary members only. By default, all members are assumed primary.

3.6.8. Wall transverse shear

This option allows to exclude the shear check in the weak direction of each leg of the selected walls.

3.7. The “Design Wizard” Ribbon Tab

The commands from this tab are used to run a preliminary design and assign to the entire structure (beams, columns and walls) a start up reinforcing.



The reinforcing assigned here is explicitly defined: number of rebars, size, location and spacing. Not just minimum required areas.

This process automatically divides all frame elements into segments and fills them with longitudinal and transverse reinforcing. Much consideration is given to rebar continuity among adjacent elements.

The reinforcing thus obtained is designed to satisfy code provisions for Strength, and Capacity design and to meet Detailing provisions. Serviceability checks should be run independently, when required.

Those locations, where a straightforward solution cannot be achieved, are left empty, waiting for direct user intervention. Incidents are signaled by proper warnings.

It should be noted that there is an infinite number of solutions for the reinforcing layout to satisfy code requirements. The choice of reinforcement is very personal and the solution proposed here is just one among many: by no means the best.

Consequently, this should be considered just as a preliminary design, to be used as a starting point from which to proceed with a more accurate definition of the final project. The remaining parts of the program are intended to assist the user in the reinforcing refinement phase, moving forward from draft to final definition and from there to the drawing phase.

After the reinforcing layout is generated by the Design Wizard, the user should proceed and run general checks for all members and for all design areas of concern: Strength, Capacity, Detailing provisions and Serviceability, if required. This will fill the result tables of the entire structure with D/C ratios and other design information, providing a full assessment of the reinforcing obtained and highlighting possible areas of concern. From here, the user can carry on applying the changes deemed necessary on an element-by-element basis and running local design-check operations.

3.7.1. Configuration parameters

This group of commands can be used to force the Design Wizard to allow some extra safety to be added, supplementary to all other Code prescribed factors. This recognizing the finality of the results obtained here, where we are dealing with actual reinforcing, not just required areas. Without extra safety, this reinforcing would be the bare minimum allowed, which sometimes could be inappropriate.

Some extra safety should be included at this level, as a minimum to account for poor judgment or approximations in the model, affecting the output from the analysis phase.

The safety factors are applied to the required areas thus increasing the total amount of reinforcing proposed. The factors can be applied separately to longitudinal and transverse reinforcing; for each, the default value is 1.05.

It is also possible to decide whether to include or exclude code minimum areas when assigning the reinforcing to the elements. This option is currently implemented only for frame elements (beams and columns).

3.7.2. Frames reinforcing parameters

Preferences for the longitudinal and transverse reinforcing of beams and columns are assigned here. Cover values specified in this section are always referred to the centroid of the longitudinal rebars.

For beam elements the reinforcing is divided into two groups, base and added reinforcement. The base reinforcement is typically continuous, while the added is not. The program will select and optimize rebar diameters, choosing from those assigned to each group. As an option, it is possible to force a symmetrical (with respect to the vertical axis of the beam) reinforcing layout in the beams.

Typically, the base reinforcing will be assigned diameters larger than (or equal to) the diameters of the added reinforcing. The user can override this preference, checking the box at the lower left corner of the window.

A distinction is also made between primary and secondary members. Seismic provisions and capacity design are not considered in the design of secondary members. Note that by default all members are assumed primary. To change the assignment to secondary, use the edit menu.


The user is also given the option to increase the beams overall bottom reinforcing, applying an increase factor to the required area. This is done by some engineers to account for creep, shrinkage and other occurrences, which may reduce negative moments at supports. This increase should not be confused with the code defined "Moment Redistribution", addressed with a specific command.

The dialog box is titled "Beam longitudinal reinforcement preferences". It is divided into two main sections: "Primary beams" and "Secondary beams". Each section contains a "Cover" field set to 0.05, a "Base rebars" section with "Available" and "Selected" lists, and an "Added rebars" section with "Available" and "Selected" lists. The "Available" lists for both sections contain diameters d 8, d 10, d 12, d 14, d 16, d 18, d 20, and d 22. The "Selected" lists for both sections contain diameters ø 16 and ø 22. At the bottom, there are fields for "Non structural rebar diameter" (set to d 8), "Bottom reinforcing increase factor" (set to 1.1), a checked "Force symmetrical reinforcement" checkbox, and an unchecked "Large diameters additional rebars" checkbox. "Ok" and "Cancel" buttons are at the bottom right.

For column elements the user can select different diameters to be used for primary and secondary members. Conventionally, the column reinforcing is not allowed to decrease from one story to the previous however the user has the option to overwrite this behavior using the "Free column reinforcement" option. Splices are normally set at the bottom of the elements but splices at middle height are also available by activating the appropriate checkbox.

The dialog box is titled "Column longitudinal reinforcement preferences". It is divided into two main sections: "Primary columns" and "Secondary columns". Each section contains a "Cover" field set to 0.05, an "Available rebars" list, and a "Selected rebars" list. The "Available rebars" lists for both sections contain diameters d 8, d 10, d 12, d 14, d 16, d 18, d 20, and d 22. The "Selected rebars" lists for both sections contain diameters ø 16 and ø 22. At the bottom, there are two unchecked checkboxes: "Free column reinforcement" and "Splices at middle height". "Ok" and "Cancel" buttons are at the bottom right.

Preferred diameters for frame transverse reinforcing can also be assigned here.




3.7.3. Walls reinforcing parameters

Preferences for the longitudinal and transverse reinforcing of wall piers and spandrels are assigned here. Cover values specified in this section are always referred to the centroid of the longitudinal rebars.

For Pier-type shear walls, in addition to the list of diameters, the user can also specify the target values of the vertical rebar spacing inside the boundary regions and the internal regions. These values are used by the program to determine the optimal diameter among those selected. Starting from the lower diameter of the list, VIS calculates the corresponding minimum spacing that would comply to the design requirements and compare it with the target value specified by the user; if the calculated spacing is equal or larger to the target then that diameter will be chosen, otherwise the software continues its search with the next diameter.

It is also possible to customize the maximum spacing allowed between the rebars placed along the thickness of the wall.



For Spandrel-type shear walls the user can specify the number and the related diameter of the edge rebars (top and bottom continuous reinforcing).

Longitudinal and transverse edge reinforcing can also be specified in terms of ideal step and list of diameters.

3.7.4. Run

This group of commands allows to start the execution of the Wizard. Once the process will be completed, the user must proceed to the check phase as described in the following paragraphs.

3.8. The “Strength” Ribbon Tab

Two separate modes can be used for “Strength” design calculations: “Design” and “Check”.



The design calculation mode provides the minimum required area of reinforcement, given concrete geometry and internal forces.

The check calculation mode provides Demand Capacity ratios (D/C) after the reinforcing has been assigned.

3.8.1. PMM Design of Single Frame Elements

Reinforcing design of frame elements subject to biaxial bending and axial load, given concrete geometry and internal forces, can generate infinite results. To attain a unique solution, two separate strategies are used: one for columns and one for beams.

For **Column Design**, VIS requires the location of all reinforcing bars to be known (user defined). The diameter is not needed. Having thus reduced the number of variables, the program can calculate the minimum amount of the reinforcing required to satisfy all strength conditions. The calculated area of reinforcing is the **total area to be divided into equal parts among all reinforcing locations**. The calculations are executed for all sets of internal forces and all stations within a given segment. The reported result is the worst possible for each segment. The minimum reinforcing area required by code is reported as well.


Column design		
Segment	Min. area required by design [mm²]	Min. area allowed by code [mm²]
1	398.2	1800
2	1.451e-09	1800
3	358.9	1800

For **Beam Design**, typically, the exact location of each rebar is not needed (the only exception being Generic Geometry beams). Following the traditional approach, all top reinforcing and bottom reinforcing are considered as collapsed onto their centroids and the only information required is the top and bottom concrete covers

(referring to these centroids). Double reinforced beams have typically infinite solutions. The criteria adopted by the program to make the solution unique, is for the tensile reinforcement to reach a given steel target strain, and, consequently, to know the location of the neutral axis.

The steel target strain is set by the user in the Strength Design Settings, within the “General Settings” ribbon tab. The default value is 0.05. The lower is the strain, even if the solution may be more economical, and the less ductile is the section behaviour. For an optimal value, the suggestion from the Eurocodes is to keep the neutral axis at about 40% of the effective depth. The corresponding target steel strain is about 5‰, thus the default value used by VIS. The ACI code requires that steel strain be at least 4‰.

Once a beam is selected and the PMM strength design button is pressed, the Beam Design window pops up showing, for each beam segment, concrete cover, target steel strain, minimum top and bottom reinforcing areas as required by design and by code minimum limits. Covers and target strains can be edited.



Segment	Concrete cover [mm]		Target steel strain	Min. area required by design [mm²]		Min. area allowed by code [mm²]	
	Top	Bottom		Top	Bottom	Top	Bottom
1	50	50	0.005	438	193.5	466.7	466.7
2	50	50	0.005	0	209.5	0	466.7
3	50	50	0.005	479.5	183.2	466.7	466.7


Generic Geometry beams require the precise coordinates of each rebar to be provided. The area calculated is the design minimum total reinforcing and needs to be divided into equal parts among all locations. Results are similar to those for columns.

3.8.2. Shear Design of Single Frame Elements

Contrary to the above, the design solution for shear reinforcing of a frame element is univocal. Output is the required area of shear reinforcing per unit length. Shear reinforcing is always assumed perpendicular to the frame direction (not diagonal) and results are provided for both local **2** and **3** directions.

E.g. if the result for a beam section is 1.27 mm²/mm and the user intends the spacing to be 150mm, the required minimum shear reinforcing area would be 1.27x150=190.5mm² to be divided among all legs. A 12mm diameter stirrup, having two legs with a total area of 226mm², satisfies the requirement.

Once the actual size and spacing of transverse reinforcing is selected, the user can assign it to the section and proceed evaluating other possible concerns, including capacity design, detailing limits, or effects of diagonal rebar.



Segment	Min. area required by design [mm²/mm]		Min. area allowed by code [mm²/mm]	
	22 Axis	33 Axis	22 Axis	33 Axis
1	1.2703	0	0.5027	0
2	0.9531	0	0.45	0
3	1.0576	0	0.5027	0

3.8.3. Design of Frame Elements All At Once

The previous commands refer to the design of a single frame element. This command runs the design of all frame elements at once, both PMM and shear.

The results are reported in the "Strength results tables". These results are provided for each segment of frame elements and are in the form of minimum required area for longitudinal and transverse reinforcing. Note that units are cm² for longitudinal rebar and cm²/cm for transverse reinforcing. Columns and beams results are kept separate.

In order to execute this command, the geometry of all sections, as well as the concrete cover for all beams and the rebar location for all columns should be preliminarily defined. In addition, K factors should be assigned to columns if different from 1.0. If the concrete section of any element is found not to be adequate, the reinforcing design for that element is not carried out and a warning is posted.

3.8.4. PMM Design of a Single Wall

This command allows to design the longitudinal reinforcing of wall piers or spandrels with reference to the analysis forces. For pier-type shear walls, it is possible to define the rebar cover, the maximum allowable reinforcing ratio and to select the design strategy for the non-critical sections (uniform reinforcing or concentrated at ends).

PMM design wall: W1

General parameters

Cover

Maximum allowed reinforcing ratio %

Design procedure for non-critical sections

☒ Uniform reinforcing

☐ Reinforcing prevailing at ends

Minimum reinforcing ratio at ends %

Section	Height	Critical	Reinforcing ratio p		Boundary regions length
			Internal regions	Boundary regions	
1B	0	<input checked="" type="checkbox"/>	0.20%	1.76%	max(0.2Lw, 1.5Bw)
1T	3	<input checked="" type="checkbox"/>	0.20%	1.00%	max(0.2Lw, 1.5Bw)
2B	3	<input checked="" type="checkbox"/>	0.20%	1.00%	max(0.2Lw, 1.5Bw)
2T	6	<input type="checkbox"/>	0.21%	0.21%	max(0.2Lw, 1.5Bw)
3B	6	<input type="checkbox"/>	0.20%	0.20%	max(0.2Lw, 1.5Bw)
3T	9	<input type="checkbox"/>	0.20%	0.20%	max(0.2Lw, 1.5Bw)
4B	9	<input type="checkbox"/>	0.20%	0.20%	max(0.2Lw, 1.5Bw)
4T	12	<input type="checkbox"/>	0.20%	0.20%	max(0.2Lw, 1.5Bw)

Design

At the end of the design, user can review the extension of the boundary regions calculated by the program for each leg of the wall by clicking on the string below the column "Boundary regions length".

Boundary regions length

Leg	Lc
1	0.45
2	0.45
3	0.45

OK

For spandrel-type walls it is possible to define the rebar cover and the maximum allowable reinforcing ratio.

PMM design wall: F1

General parameters

Cover

Maximum allowed reinforcing ratio %

Section	Station	Reinforcing ratio ρ
0	0	0.12%
1	2	0.12%

Design

3.8.5. Shear Design of a Single Wall

This command allows to design the shear reinforcing of a pier- or spandrel-type shear wall with reference to the analysis forces. In some cases, on the basis of the selected design code and internal forces, a trial reinforcing must be preliminary assigned to all the sections of the wall in order to perform the design.

In the case of pier-type walls the software will calculate, for each leg of the section, the requested horizontal and vertical reinforcing ratios and the potential diagonal reinforcing area necessary for the sliding check of the critical sections.

Shear design of wall W3-MULT

Section	Leg	RhoH	RhoV	Diagonal area [m ²]	Diagonal reinforcement inclination [°]
1B	1	0.169%	0.000%	0	45
	2	0.212%	0.000%	0	45
	3	0.169%	0.000%	0	45
1T	1	0.144%	0.000%	0	45
	2	0.185%	0.000%	0	45
	3	0.143%	0.000%	0	45
2B	1	0.162%	0.000%	0	45
	2	0.253%	0.000%	0	45
	3	0.161%	0.000%	0	45
2T	1	0.160%	0.000%		
	2	0.262%	0.000%		
	3	0.159%	0.000%		

OK

For spandrel-type walls the program will report the requested shear reinforcing ratio or, if the case, the diagonal reinforcing area.

Section	Leg	Diagonal area [m ²]	Diagonal reinforcement inclination [°]
0	1	0.00138	45
1	1	0.00138	45

OK

3.8.6. Design of Walls All At Once


This command performs the design of the longitudinal and shear reinforcing of all the walls of the model (both piers- and spandrel-type) at once with reference to the analysis forces. The design parameters used in the calculations are those specified in the “General settings” tab. The design results are available through the “Results > Strength > Wall design” menu.

Strength results									
Beam design Column design Wall design Beam PMM checks Column PMM checks Beam V checks Column V checks Wall PMM checks Wall V checks									
Wall	Section	Station [m]	PMM Design				Shear Design		
			Reinforcing ratio		Boundary regions length [m]		Reinforcing ratio		A _i
			Internal regions	Boundary regions			Transversal	Longitudinal	
W1	1B	0	0.20%	1.76%	0.6		0.18%	0.00%	0
	1T	3	0.20%	1.00%	0.6		0.18%	0.00%	0
	2B	3	0.20%	1.00%	0.6		0.01%	0.00%	0
	2T	6	0.21%	0.21%	0.6		0.04%	0.00%	
	3B	6	0.20%	0.20%	0.6		0.01%	0.00%	
	3T	9	0.20%	0.20%	0.6		0.04%	0.00%	
	4B	9	0.20%	0.20%	0.6		0.00%	0.00%	
	4T	12	0.20%	0.20%	0.6		0.00%	0.00%	
W2	1B	0	0.20%	1.71%	0.6		0.17%	0.00%	0
	1T	3	0.20%	1.00%	0.6		0.17%	0.00%	0
	2B	3	0.20%	1.00%	0.6		0.01%	0.00%	0
	2T	6	0.21%	0.21%	0.6		0.04%	0.00%	
	3B	6	0.20%	0.20%	0.6		0.01%	0.00%	
	3T	9	0.20%	0.20%	0.6		0.04%	0.00%	
	4B	9	0.20%	0.20%	0.6		0.00%	0.00%	
	4T	12	0.20%	0.20%	0.6		0.00%	0.00%	

OK

3.8.7. PMM Check of Single Frame Elements

After the reinforcing is assigned, the frame PMM check button can be used to open the strength check window for biaxial bending and axial compression of a selected frame element. Beams and columns are treated similarly, but columns have additional checks addressing imperfections and slenderness.



On the upper left side of the window, the user can move between the various segments of the element.

Right below, a check table reports the internal forces for all load combinations and all stations within the chosen segment. Each row refers to a single set of internal forces: N , M_3 , and M_2 . The last cell reports the pertaining result. Results are in the form of Demand Capacity ratios.

The force sets are those imported from SAP2000 or defined in the "Internal forces" table from the "Define" ribbon tab. Here, however, the user can try out different forces, if desired by filling up the "Force Check" text boxes below the spreadsheet.

For each force set, the check results are printed green if satisfactory, red if not. Demand Capacity ratios are "radial". They are calculated in the N , M_2 , M_3 space on a segment from the origin, through the force, and to the surface of the interaction diagram.


Once D/C ratios for all the internal forces are verified at a glance, the user can select those more interesting and generate interaction diagrams, either in the MM or MN planes. These are reported on the right side of the window. The planes are those through the selected force set. The segment for the calculation of the D/C ratio is represented as well. With a right click of the mouse over the diagram, information that is more detailed can be obtained.

2D interaction diagrams for different planes, both horizontal and vertical, can be obtained clicking the "Plot" buttons.

Clicking the “Export” button, the graphic representation of 2D interaction diagrams can be exported in the EMF format (used by Microsoft Word and other software) as vector graphics images and later pasted onto calculation reports.

The numerical values of 2D interaction diagrams can be copied and later pasted onto a spreadsheet for further use clicking the “Copy” button

A full 3D representation of the interaction diagram can be obtained by clicking the “3D view” button. Points representing the various force sets are represented as well. The representation can be further refined, using tools recalled by the right click of the mouse.



Columns

Results for columns are different from those for beams, since they also need to include moments due to slenderness and geometric imperfections. For this reason, columns have generally two or three check tables instead of only one. Precisely:

- Analysis: the design moments are those imported directly from analysis, without added or magnified moments. Checks are reported at each station and for each load combination. The table is the same as for beams.
- Imperfections: the design moments are those from analysis with the added effect of imperfections (or minimum eccentricity, if worse). Checks are reported for each load combination and each station.
- Slenderness: the design moment is the sum of the first order equivalent moment, including the effect of geometric imperfections and the second order moment. The table is reported only when applicable (i.e., column is slender). Checks refer to the entire column, since a single equivalent first order moment is used. Results are given for each load combination.

For the column to be acceptable, checks need to be satisfied by all reported tables. For practical purposes, the worst D/C result is reported for each table, near the table title tab. The worst result overall is reported for each segment, near the segment itself.

Note the following:

- The method used for slenderness calculations is based on nominal stiffness or nominal curvature method.
- Columns are assumed loaded only at ends.
- The axial load is assumed constant along the element (maximum value is used).
- The section is assumed constant throughout the column.
- For sway frames, the user should also select the proper bending mode under seismic actions, either single or double curvature.
- Slenderness calculations are necessarily referred to the column Principal Axes of Inertia, major and minor. Thus, K factors, as defined from the “Edit” ribbon tab, are referred to the Principal Axes, not the local axes. See also paragraph 2.3 and paragraph 3.8.2.

Detailed information on column checks can be obtained by clicking the button “Details” and opening the column checks window.

This window has two tabs. The “Calculation data” tab has information on all data used for column slenderness and eccentricity calculations. The “Amplified Moments” tab reports the bending moments magnified with imperfections and second order effects.

Note that all information here refers to the Principal, rather than the local axes (as in the previous window).

EC2 UNI ENV 2005 column checks

Calculation data

Magnified bending moments

Design loads and lambda limit (slenderness limit)

#	Load case	Case type	N Ed	Major axis M01	Major axis M02	Major axis λ lim	Minor axis M01	Minor axis M02	Minor axis λ lim
1	STR1	Combination	-4.95e+05	-2.13e+06	-2.61e+06	39.3	2.67e+07	-2.84e+07	117
2	STR2	Combination	-4.86e+05	-1.84e+06	-2.73e+06	46.2	2.65e+07	-2.85e+07	118
3	STR3	Combination	-5.92e+05	-2.8e+06	-2.94e+06	30.5	3.8e+07	-4.08e+07	107
4	STR4	Combination	-4.94e+05	-1.87e+06	-2.77e+06	45.7	2.64e+07	-2.84e+07	117
5	STR5	Combination	-6e+05	-2.84e+06	-2.98e+06	30.2	3.79e+07	-4.07e+07	107
6	STR6	Combination	-5.9e+05	-2.68e+06	-2.96e+06	32.4	3.77e+07	-4.08e+07	107
7	STR7	Combination	-5.98e+05	-2.71e+06	-2.99e+06	32.2	3.77e+07	-4.06e+07	106
8	STR8	Combination	-4.87e+05	-2.1e+06	-2.57e+06	39.7	2.67e+07	-2.86e+07	118
9	STR9	Combination	-5.07e+05	-2.18e+06	-2.66e+06	38.8	2.66e+07	-2.83e+07	116
10	STR10	Combination	-5.05e+05	-1.91e+06	-2.82e+06	45	2.63e+07	-2.83e+07	116

Slenderness at principal axes

A	1.8e+05	
	Major axis	Minor axis
I ₀	9e+03	9e+03
e	173	86.6
λ	52	104

Eccentricity


	#	Major axis	Minor axis
e ₀	1	4.88	23
	2	4.89	23.5
	3	4.88	27.6
e _i		22.5	22.5
	1	79.6	142
e ₂	2	79.4	142
	3	82	146
	4	79.6	142
e _{Min}		20	20

3.8.8. Shear Check of Single Frame Elements

After the reinforcing is assigned, the frame V check button can be used to run a shear strength check for a selected frame element. The button is active only if the "Enable shear check" selection box is checked in the section properties definition form, for the section in use (see the "Define" ribbon tab).

Checks are based on the strut and tie method, with variable or fixed angle as set for by the user from the "General Settings" ribbon tab (Ref. paragraph 3.6.2).

The result window is as shown below. On the upper part of the window, the frame element and its segments are represented. The user can select a segment by double clicking. The worst D/C result is reported below each segment. Detailed checks for the selected segment are reported over two similar tabs: one for each local direction.



For the verification of the shear resistance according to the Eurocode, the following symbols are used:

- V_{Ed} Highest design value of the applied shear force for the selected segment
- $V_{Rd,c}$ design shear resistance of the member without shear reinforcement
- $V_{Rd,max}$ design value of the maximum shear force which can be sustained by the member, limited by crushing of the compression struts
- $V_{Rd,s}$ design value of the shear force which can be sustained by the yielding shear reinforcement

The shear strength check for unreinforced sections, requires that $V_{Ed} \leq V_{Rd}$; for reinforced section that $V_{Ed} \leq V_{Rd,c}$ and $V_{Ed} \leq V_{Rd,s}$

The lower part of the window shows the message "Section is adequate" (green) or "Section is not adequate" (red). In the latter case, the equation(s) not verified are shown.


3.8.9. Checks of Frame Elements All At Once

The previous commands refer to the check of a single frame element. This command runs the check of all frame elements at once, both PMM and shear.

In order to execute this command, the geometry and reinforcing of all sections should be preliminarily defined. In addition, bending mode and K factors should be assigned to columns.

The results are reported in the "Strength results tables", from the "Results" ribbon tab. These results are provided for each segment of all columns and beams and are in the form of Demand Capacity ratios. Tables for beams and columns are kept separate.

From the same tab, results can also be viewed graphically. Here Demand/ Capacity ratios are represented with a color coded graphic display of the structural model. Outputs from each limit state are kept separate.



3.8.10. PMM Check of Single Wall-Stacks

After the reinforcing is assigned, the button for wall PMM checks can be used for biaxial bending and axial compression strength checks for a selected Wall-stack.

Checks are based on all combinations of applied internal forces, as derived from the analysis, and results are provided as Demand Capacity ratios for the selected Wall-stack section.

Click the "Interaction diagrams" button to access the "Interaction diagram" window for the selected wall section. This is similar to the interaction diagram window for columns.

Wall PMM check

NUCLEO

- 03 (0.20)
- 00 (1.02)
- 03 (0.57)
- 06 (0.13)
- 09 (0.11)
- 12 (0.02)

Interaction diagrams

	Combination	Seismic	N	M3	M2	D/C
24	QKE1	✓	-1.469e+06	-1.092e+09	-2.886e+09	0.527
25	QKE1	✓	-1.469e+06	6.467e+08	-2.886e+09	0.51
26	QKE1	✓	-1.469e+06	-1.092e+09	2.93e+09	0.97
27	QKE1	✓	-1.469e+06	6.467e+08	2.93e+09	0.944
28	QKE1	✓	-1.291e+06	-1.092e+09	-2.886e+09	0.573
29	QKE1	✓	-1.291e+06	6.467e+08	-2.886e+09	0.555
30	QKE1	✓	-1.291e+06	-1.092e+09	2.93e+09	1.02
31	QKE1	✓	-1.291e+06	6.467e+08	2.93e+09	1.01
32	QKE2	✓	-1.469e+06	-1.092e+09	-2.886e+09	0.527
33	QKE2	✓	-1.469e+06	6.467e+08	-2.886e+09	0.51
34	QKE2	✓	-1.469e+06	-1.092e+09	2.93e+09	0.97
35	QKE2	✓	-1.469e+06	6.467e+08	2.93e+09	0.944
36	QKE2	✓	-1.291e+06	-1.092e+09	-2.886e+09	0.573
37	QKE2	✓	-1.291e+06	6.467e+08	-2.886e+09	0.555
38	QKE2	✓	-1.291e+06	-1.092e+09	2.93e+09	1.02
39	QKE2	✓	-1.291e+06	6.467e+08	2.93e+09	1.01
40	QKE3	✓	-1.465e+06	-9.256e+08	-2.995e+09	0.553
41	QKE3	✓	-1.465e+06	8.129e+08	-2.995e+09	0.55
42	QKE3	✓	-1.465e+06	-9.256e+08	2.821e+09	0.908
43	QKE3	✓	-1.465e+06	8.129e+08	2.821e+09	0.896
44	QKE3	✓	-1.287e+06	-9.256e+08	-2.995e+09	0.598

3.8.11. Shear Check of Single Wall-Stacks

After the reinforcing is assigned, the wall V check button can be used to open the shear strength window for a selected Wall-stack.

Checks are based on all combinations of applied shear and axial force, as derived from the analysis, and results are provided as Demand Capacity ratios for the selected Wall-stack section. If in a critical region, the section is checked also for sliding shear failure. Two results tables are provided, one for each local direction.

For Eurocode design code, notation is as follows:

V_{Ed}	Highest design value of the applied shear force for the selected segment
$V_{Rd,c}$	Design shear resistance of the member without shear reinforcement
$V_{Rd,max}$	Design value of the maximum shear force which can be sustained by the member, limited by crushing of the compression struts
$V_{Rd,s}$	Design value of the shear force which can be sustained by the yielding shear reinforcement
$V_{Rd,S}$	Design value of shear resistance against sliding
$D/C = V_{Ed}/V_{Rd}$	Demand Capacity ratio for shear strength

$D/C = f(\rho_v, \rho_h)$ Demand Capacity ratio for vertical and horizontal reinforcement, when $\alpha_s < 2.0$ (see EC8 §5.5.3.4.3 Eqn. 5.39)

$D/C = 2 \cdot V_{Ed}/V_{td}$ Demand Capacity ratio at squat walls with inclined bars

Wall shear checks

3 Direction

	Combination	Seismic	VEd	VRd,c	VRd,max	VRd,s	VRd,S	D/C = VEd/VRd	D/C = f(pv,ph)	D/C = VEd/Vtd
18	STR18	<input type="checkbox"/>	9767	-	4.063e+06	9.835e+05	8.547e+05	0.01143	-	-
19	STR19	<input type="checkbox"/>	9951	-	4.066e+06	9.835e+05	8.567e+05	0.01161	-	-
20	STR20	<input type="checkbox"/>	6087	-	4.045e+06	9.835e+05	8.446e+05	0.007206	-	-
21	STR21	<input type="checkbox"/>	1.32e+04	-	4.056e+06	9.835e+05	8.509e+05	0.01551	-	-
22	STR22	<input type="checkbox"/>	2878	-	4.056e+06	9.835e+05	8.509e+05	0.003383	-	-
23	STR23	<input type="checkbox"/>	9989	-	4.067e+06	9.835e+05	8.571e+05	0.01165	-	-
24	QKE1	<input checked="" type="checkbox"/>	-8.016e+05	-	1.573e+06	9.835e+05	7.829e+05	1.024	-	-
25	QKE1	<input checked="" type="checkbox"/>	7.732e+05	-	1.573e+06	9.835e+05	7.829e+05	0.9877	-	-
26	QKE1	<input checked="" type="checkbox"/>	-8.016e+05	-	1.573e+06	9.835e+05	7.829e+05	1.024	-	-

2 Direction

	Combination	Seismic	VEd	VRd,c	VRd,max	VRd,s	VRd,S	D/C = VEd/VRd	D/C = f(pv,ph)	D/C = VEd/Vtd
50	QKE4	<input checked="" type="checkbox"/>	1.517e+05	-	7.855e+05	4.917e+05	3.686e+05	0.4115	-	-
51	QKE4	<input checked="" type="checkbox"/>	1.517e+05	-	7.855e+05	4.917e+05	3.686e+05	0.4115	-	-
52	QKE4	<input checked="" type="checkbox"/>	-9.874e+04	-	7.81e+05	4.917e+05	3.61e+05	0.2735	-	-
53	QKE4	<input checked="" type="checkbox"/>	-9.874e+04	-	7.81e+05	4.917e+05	3.61e+05	0.2735	-	-
54	QKE4	<input checked="" type="checkbox"/>	1.517e+05	-	7.81e+05	4.917e+05	3.61e+05	0.4202	-	-
55	QKE4	<input checked="" type="checkbox"/>	1.517e+05	-	7.81e+05	4.917e+05	3.61e+05	0.4202	-	-
56	QKE5	<input checked="" type="checkbox"/>	-3.181e+05	-	7.855e+05	4.917e+05	3.672e+05	0.8663	-	-
57	QKE5	<input checked="" type="checkbox"/>	-3.181e+05	-	7.855e+05	4.917e+05	3.672e+05	0.8663	-	-
58	QKE5	<input checked="" type="checkbox"/>	3.95e+05	-	7.855e+05	4.917e+05	3.672e+05	1.076	-	-

3.8.12. Checks of All Walls At Once


The previous commands refer to the check of single Wall-stacks. This command runs the check of all walls at once, both PMM and shear.

In order to execute this command, the geometry and reinforcing of all sections, should be preliminarily defined. The results are reported in the "Strength results tables" in the "Results" ribbon tab. These results are provided for each section of all Wall-stacks and are in the form of Demand Capacity ratios. PMM and shear tables are kept separate.

From the same tab, results can also be viewed graphically. Here Demand/ Capacity ratios are represented with a color-coded graphic display of the structural model. Outputs from each limit state are kept separate.

3.8.13. Joints check

This command is active only when the code is set to Italian NTC 2018 and the structure has been defined as "existing structure". In this case the principal stresses acting in the center of the selected joint pane will be calculated and compared with the admissible values allowed by the code. When the "Check all frames" command is run, the checks of all the joints will be performed as well and the corresponding results will be available in the Results > Strength > Joint Checks table.




3.9. The “Capacity” Ribbon Tab

Capacity design is implemented only for EC2-2005 and NTC-2008. The following settings need to be initially assigned from the “General Settings” ribbon tab:


- Desired code
- Seismic design
- Ductility class

Furthermore, a preliminary layout of all concrete reinforcing needs to have been assigned based on strength considerations, before capacity design can be performed. This can be done by the user based on his experience or using the Wizard and the strength design tools. Only then, the design process can proceed and modify the reinforcement in accordance with capacity criteria.



3.9.1. Design for Strong-Column Weak-Beam Action at Single Joints

Design and check of column reinforcing can be performed at each joint, based on strong-column weak-beam action. Reinforcing of columns is calculated from the actual reinforcing of beams; while beam reinforcing, as defined from preliminary design, should meet strength requirements.



The chosen joint needs to be defined first, by selecting all elements framing into it. Once the joint is defined, the “Column PMM” button opens a window where the joint geometry is recalled. This window is common to both the design and check phases.

Angles between beams and columns can be various, but columns need to be vertical and beams horizontal. There is no restriction on the number of beams. The rotation angles of all beams and of the upper column are reported with reference to axis **3** of the lower column.


Click the design button for design results. Based on beam reinforcing, the program calculates the sum of resisting moments from all beams, which is then equated to the sum of the required column minimum resisting moments allowing for steel strain hardening factors. The inequality condition reads as follow:

$$\sum M_{C,Rd} \geq \gamma_{Rd} \cdot \sum M_{b,Rd}$$

The total resisting moment required for top and bottom columns is thus obtained. To make the solution univocal, the column resisting moments are then assigned to each, according to the distribution rule selected in the “General settings > Seismic” tab. The possible choices are:

- automatic distribution proportional to the analysis moments. In this case, if the bending moments on the top and bottom faces of the joint have the same sign, all the strength is assigned to the bottom column while the resisting moment of the top column is summed together with those of the beams.
- Fixed distribution, defined by the user as $A_{s,top}/A_{s,bot}$ ratio.
- Automatic distribution based on the area ratio calculated through the strength design of the top and bottom columns at joint faces (default option).

Given the large number of load combinations, a cloud of possible results is obtained. The program subsequently calculates the minimum reinforcing area required to envelope all resisting moments thus defined, accounting for axial load as well.



Output is the total required reinforcing for both top and bottom columns. The reinforcing area needs to be uniformly divided among all rebar, maintaining the rebar location originally assigned during preliminary design.

3.9.2. Shear Design of Single Beam-Column Joints

The “Joint V” button performs the joint shear capacity design.

Output provides the minimum transverse reinforcing area to be placed within the panel zone, to meet the shear demand associated with the formation of plastic hinges at the beams entering the joint. Calculations account for column applied shear force and steel strain hardening.

Preliminarily, the program checks the compression strut. If the concrete strength is not adequate, the program does not proceed and an error message is issued, suggesting an increase in the size of the column.

If compression strut resistance is adequate, the program proceeds, designing the required transverse reinforcement with two separate methods:

Confined concrete: shear resistance is provided by confined concrete. Confinement reinforcing is designed accordingly.

Tie action: shear resistance is provided by reinforcing, acting according to the strut, and tie model. Shear reinforcement is designed accordingly.

Joint shear capacity design

Joint 42 Joint is confined

Connectivity data

Element	Name	Rotation angle	Element end
C1		116	I
Cb		28	J
B1		54	90 J
B2		56	270 I
B3		92	180 J
B4		94	0 I

Equivalent planar joints geometry


Direction	bj [mm]	hjc [mm]	hfw [mm]	As1,sx [mm²]	As2,sx [mm²]	As1,dx [mm²]	As2,dx [mm²]	Ash [mm²]
3	600	300	150	804	804	804	804	804
2	600	300	150	1.41e+03	804	1.41e+03	804	804

Materials


fcd [kN/mm²]	fcid [kN/mm²]	fyd [kN/mm²]	fywd [kN/mm²]	γRd	η2	η3
0.0142	0.0012	0.391	0.391	1.10	0.54	0.54

Checks

Direction	Vjbd.1 [kN]	Vjbd.2 [kN]	vd			D/C		Ash [mm²]	
			Comp.	Confin.	Stirrups	Comp.	Confin.	Stirrups	
3	677	677	0.282	0.269	0.269	0.711	374	1.39e+03	
2	946	946	0.282	0.269	0.269	0.994	993	1.91e+03	



Equivalent planar joint



OK

Adequacy of just one of the two methods suffices. The user should consider only the more favorable of the two results.

Result is the total cross sectional area of horizontal hoops and cross ties within the height of the entire joint. It is provided for each local direction.

3.9.3. Shear Design of Single Frame Elements

The Design Frame V button opens the shear design window. This window provides design of transverse reinforcing of columns and beams, in accordance with capacity design criteria set by codes.

The design shear force acting at the end of the beam or column is obtained applying the capacity design rule to the member, i.e. applying to the member ends their resisting moments and obtaining the shear force, required by equilibrium, with allowance for steel strain hardening.


$$V_{Ed} = \gamma_{Rd} \cdot \frac{M_{C,Rd}^s + M_{C,Rd}^i}{l}$$

At columns, the calculation of the end resisting moments keeps into account the acting axial force. At beams, the equilibrium calculations include the external loads applied along the beam, as derived from seismic load combinations.

Note: design can be performed only after the longitudinal reinforcing is completely defined.

Output is the required area of shear reinforcing per unit length of frame element. It refers to the total shear reinforcing area (sum of all legs), assumed to be perpendicular to the frame direction (not diagonal). The capacity design applied shear V_{Ed} is reported as well.

Results are provided for each segment. At columns, for both **2** and **3** local axes are addressed.



Segment	VEd [N]		Min. area required by design [mm²/mm]	
	22 Axis	33 Axis	22 Axis	33 Axis
1	2.117e+05	7950	0.005046	0.0004191
2	2.117e+05	7950	0.005046	0.0004191
3	2.117e+05	7950	0.005046	0.0004191

3.9.4. Design of Frame Members All At Once

The previous commands refer to the design of single members (columns, beams, joints). This command runs the design of all members at once.

The results are reported in the "Capacity results" window from the "Results" ribbon tab. These results are organized in tables, where columns, beams, and joints are kept separate.

Note that units are cm² for longitudinal rebar and joint (total) transverse reinforcement, while cm²/cm for frame transverse reinforcing.

In order to execute this command, it is required for the preliminary reinforcing of all members to be already assigned, based on strength criteria. Design results at some locations could possibly be not achievable because of inadequate concrete sections. In this case, results are left blank.

3.9.5. PMM Design of a Single Wall

This command allows to design the longitudinal reinforcing of a pier-type shear wall with reference to the amplified forces calculated according to the capacity design rules for the selected design code.

The design settings and the design output are very similar to those related to the corresponding PMM strength design window.

PMM capacity design wall: W3-MULT

General parameters

Cover

Maximum allowed reinforcing ratio

Design procedure for non-critical sections

☒ Uniform reinforcing

☐ Reinforcing prevailing at ends

Minimum reinforcing ratio at ends

Section	Height	Critical	Reinforcing ratio p		Boundary regions length
			Internal regions	Boundary regions	
1B	0	<input checked="" type="checkbox"/>	0.20%	1.76%	max(0.2lw, 1.5bw)
1T	3	<input checked="" type="checkbox"/>	0.20%	1.81%	max(0.2lw, 1.5bw)
2B	3	<input checked="" type="checkbox"/>	0.20%	1.81%	max(0.2lw, 1.5bw)
2T	6	<input type="checkbox"/>	0.52%	0.52%	max(0.2lw, 1.5bw)
3B	6	<input type="checkbox"/>	0.53%	0.53%	max(0.2lw, 1.5bw)
3T	9	<input type="checkbox"/>	0.32%	0.32%	max(0.2lw, 1.5bw)
4B	9	<input type="checkbox"/>	0.33%	0.33%	max(0.2lw, 1.5bw)
4T	12	<input type="checkbox"/>	0.20%	0.20%	max(0.2lw, 1.5bw)

Design

3.9.6. Shear Design of a Single Wall

This command allows to design the shear reinforcing of a pier- or spandrel-type shear wall with reference to the amplified forces calculated according to the capacity design rules for the selected design code. In some cases, on the basis of the selected design code and internal forces, a trial reinforcing must be preliminary assigned to all the sections of the wall in order to perform the design.

The design settings and the design output are very similar to those related to the corresponding shear strength design window.

Shear capacity design of wall W3-MULT

Section	Leg	RhoH	RhoV	Diagonal area [m²]	Diagonal reinforcement inclination [°]
1B	1	0.254%	0.000%	0	45
	2	0.318%	0.000%	0	45
	3	0.253%	0.000%	0	45
1T	1	0.215%	0.000%	0	45
	2	0.278%	0.000%	0	45
	3	0.215%	0.000%	0	45

OK

3.9.7. Design of Wall All At Once

This command allows to design the longitudinal and shear reinforcing of all the walls in the model (both pier- and spandrel-type) with reference to the amplified forces calculated according to the capacity design rules for the selected design code. The design parameters used in the calculations are those specified in the “General settings” tab. The design results are available through the “Results > Capacity > Wall design” menu.

Capacity results

Beam design

Column design

Joint design

Wall design

Column PMM checks

Beam V checks

Column V checks

Joint checks

Wall PMM checks

Wall V checks

Wall	Section	Station [m]	PMM Design			Shear Design			A _i
			Reinforcing ratio		Boundary regions length [m]	Reinforcing ratio			
			Internal regions	Boundary regions		Transversal	Longitudinal		
W3-SINGLE	1B_1	0	0.20%	1.76%	0.45	0.21%	0.00%		
	1B_2				0.45	0.29%	0.00%		
	1B_3				0.45	0.21%	0.00%		
	1T_1	3	0.20%	1.81%	0.45	0.21%	0.00%		
	1T_2				0.45	0.29%	0.00%		
	1T_3				0.45	0.21%	0.00%		
	2B_1	3	0.20%	1.81%	0.45	0.19%	0.00%		
	2B_2				0.45	0.13%	0.00%		
	2B_3				0.45	0.19%	0.00%		
	2T_1	6	0.52%	0.52%	0.45	0.19%	0.00%		
	2T_2				0.45	0.40%	0.00%		
	2T_3				0.45	0.19%	0.00%		
	3B_1	6	0.53%	0.53%	0.45	0.16%	0.00%		
	3B_2				0.45	0.30%	0.00%		
	3B_3				0.45	0.16%	0.00%		
	3T_1	9	0.32%	0.32%	0.45	0.15%	0.00%		
	3T_2				0.45	0.29%	0.00%		
	3T_3				0.45	0.15%	0.00%		
	4B_1	9	0.33%	0.33%	0.45	0.10%	0.00%		
	4B_2				0.45	0.16%	0.00%		
	4B_3				0.45	0.10%	0.00%		
	4T_1	12	0.20%	0.20%	0.45	0.10%	0.00%		
	4T_2				0.45	0.15%	0.00%		
	4T_3				0.45	0.10%	0.00%		

OK

3.9.8. Check for Strong-Column Weak-Beam Action at Single Joints


In most common cases, beam-column intersections belong to planar frames and results are immediately understood. The general case, however, has beams framing into the joint from more directions (e.g. corner columns). If this happens, the results are more complex and need to be regarded in a three dimensional PMM space.

The chosen joint needs to be defined first, by selecting all elements framing into it. Once the joint is defined, the “Column PMM” button opens a window where the joint geometry is recalled. This window is common to both the design and check phases.

There can be varying angles between beams and columns, but columns need to be vertical and beams horizontal. Number of beams can be any. The rotation angles of

all beams and of the upper column are reported, with reference to axis **3** of the lower column.

Click the check button to open two results windows: numerical and graphical. The MM interaction diagram of the sum of the resisting moments from the columns is compared with the MM interaction diagram of the sum of the resisting moments from the beams. This is done at minimum and maximum N locations.




Numerical results: D/C ratios are provided at significant MM locations, namely at the vertexes of the beams interaction diagram.

Graphical results: the graphic representation of the columns sum (green) and the beams sum (red) interaction diagrams is superimposed. For the check to be satisfied, the beams diagram needs to be entirely encompassed by the columns diagram.

3.9.9. Shear Check of Single Beam-Column Joints

The "Joint V" button performs the joint shear capacity check, based on reinforcing previously assigned.



The program provides the calculated shear demand V_{jhd} for the two joint rotation cases (clockwise and anti-clockwise) and the two joint local directions. Based on this shear demand, Capacity ratios are calculated for the following:

- Diagonal compression strut
- Confinement reinforcement
- Diagonal tension tie

The check for diagonal tension reinforcement is performed only if confinement reinforcement does not meet demand.

3.9.10. Shear Check of Single Frame Elements

The Check Frame V button opens the shear check window. This window checks transverse reinforcing previously assigned to columns and beams, in accordance with capacity design criteria, set by code. See paragraph 3.12.3 for details.

Results are provided for each segment. At columns, design is for both 2 and 3 local directions.

Frame capacity checks - Shear reinforcing

Segment	Reinforcing assigned [mm²/mm]		VEd [N]		VRd [N]		D/C	
	22 Axis	33 Axis	22 Axis	33 Axis	22 Axis	33 Axis	22 Axis	33 Axis
1	2.534	2.534	2.117e+05	7950	4.229e+05	1.858e+05	0.501	0.0428
2	2.534	2.534	2.117e+05	7950	5.137e+05	3.911e+05	0.437	0.0225
3	2.534	2.534	2.117e+05	7950	4.229e+05	1.858e+05	0.501	0.0428

3.9.11. Checks of Frame Members All At Once

The previous commands refer to the check of single members (columns, beams, joints). This command runs the checks of all members at once.

Before checks can be run, reinforcement needs to be assigned to all members, based on capacity design criteria as well as strength.


The results are reported in the "Capacity results" window from the "Results" ribbon tab. Results are reported in worksheet tables, as Demand Capacity ratios, from bending and shear reinforcing checks. Columns, beams, and joints are kept separate.

From the same tab, results can also be viewed graphically. Here Demand/ Capacity ratios are represented with a color coded graphic display of the structural model. Outputs from each limit state are kept separate.

3.9.12. PMM Check of Single Wall-Stacks

The Check PMM wall button runs PMM checks for a selected Wall-stack and opens the capacity check resulting window. Results are provided as Demand Capacity ratios.


Applied bending moments are vertically displaced, as required by code. At large walls, additional axial force is accounted for, where cracks or uplift may occur. Checks refer to all possible permutations of bending and axial forces.



Combination	Seismic	N	M3	M2	D/C
QKE1	✓	-1.815e+06	-1.092e+09	-2.886e+09	0.453
QKE1	✓	-1.815e+06	-1.092e+09	2.93e+09	0.865
QKE1	✓	-1.815e+06	6.467e+08	-2.886e+09	0.438
QKE1	✓	-1.815e+06	6.467e+08	2.93e+09	0.829
QKE1	✓	-1.623e+06	-1.092e+09	-2.886e+09	0.492
QKE1	✓	-1.623e+06	-1.092e+09	2.93e+09	0.923
QKE1	✓	-1.623e+06	6.467e+08	-2.886e+09	0.474
QKE1	✓	-1.623e+06	6.467e+08	2.93e+09	0.891
QKE2	✓	-1.815e+06	-1.092e+09	-2.886e+09	0.453
QKE2	✓	-1.815e+06	-1.092e+09	2.93e+09	0.865
QKE2	✓	-1.815e+06	6.467e+08	-2.886e+09	0.438
QKE2	✓	-1.815e+06	6.467e+08	2.93e+09	0.829
QKE2	✓	-1.623e+06	-1.092e+09	-2.886e+09	0.492
QKE2	✓	-1.623e+06	-1.092e+09	2.93e+09	0.923
QKE2	✓	-1.623e+06	6.467e+08	-2.886e+09	0.474
QKE2	✓	-1.623e+06	6.467e+08	2.93e+09	0.891
QKE3	✓	-1.81e+06	-9.256e+08	-2.995e+09	0.476
QKE3	✓	-1.81e+06	-9.256e+08	2.821e+09	0.805
QKE3	✓	-1.81e+06	8.129e+08	-2.995e+09	0.474
QKE3	✓	-1.81e+06	8.129e+08	2.821e+09	0.793
QKE3	✓	-1.618e+06	-9.256e+08	-2.995e+09	0.514

Click the “Interaction diagrams” button to access the graphic display of the interaction diagrams for the Wall-stack section presently selected. This window is similar to that described for frame elements.

Click the “Amplified diagrams” button to access a graphic display of the envelope diagram of amplified internal forces, N, M2 and M3, as distributed along the length of the wall.



3.9.13. Shear Check of Single Wall-Stacks

This command runs capacity shear checks for a selected Wall-stack and opens the resulting window.

Wall shear capacity check

NUCLEO

- 03 (1.53)
- 00 (1.50)
- 01 (1.48)**
- 06 (0.99)
- 09 (0.48)
- 12 (0.45)

Show diagram

3 Direction							
Combination	Seismic	VEd	VRd,c	VRd,max	VRd,s	VRd,S	D/C
24	QKE1	✓	7.495e+05	-	3.831e+06	9.835e+05	0.7622
25	QKE1	✓	7.495e+05	-	3.831e+06	9.835e+05	0.7622
26	QKE1	✓	7.495e+05	-	3.831e+06	9.835e+05	0.7622
27	QKE1	✓	7.495e+05	-	3.831e+06	9.835e+05	0.7622
28	QKE1	✓	7.495e+05	-	3.811e+06	9.835e+05	0.7622
29	QKE1	✓	7.495e+05	-	3.811e+06	9.835e+05	0.7622
30	QKE1	✓	7.495e+05	-	3.811e+06	9.835e+05	0.7622
31	QKE1	✓	7.495e+05	-	3.811e+06	9.835e+05	0.7622

2 Direction							
Combination	Seismic	VEd	VRd,c	VRd,max	VRd,s	VRd,S	D/C
50	QKE4	✓	2.69e+05	-	1.915e+06	4.917e+05	0.5471
51	QKE4	✓	2.69e+05	-	1.915e+06	4.917e+05	0.5471
52	QKE4	✓	2.69e+05	-	1.905e+06	4.917e+05	0.5471
53	QKE4	✓	2.69e+05	-	1.905e+06	4.917e+05	0.5471
54	QKE4	✓	2.69e+05	-	1.905e+06	4.917e+05	0.5471
55	QKE4	✓	2.69e+05	-	1.905e+06	4.917e+05	0.5471
56	QKE5	✓	6.826e+05	-	1.913e+06	4.917e+05	1.388
57	QKE5	✓	6.826e+05	-	1.913e+06	4.917e+05	1.388


Shear diagrams are amplified according to code specifications, based on ductility class, structural type (whether dual system or not), and structure behavior factor q .

At large walls, the dynamic component of the axial force is accounted for, where cracks or uplift may occur. The additional axial force is added or subtracted. The resisting shear force is calculated accounting for the worst condition.

Shear sliding checks are run at critical regions.

Checks are performed for each local direction and results are provided as Demand Capacity ratios.

Click the “Amplified diagrams” button to access a graphic display of the amplified shear forces envelope diagram, as distributed along the length of the wall.



3.9.14. Checks of All Walls At Once

The previous commands refer to the check of single Wall-stacks. This command runs the checks of all walls at once, both PMM and shear.

The results are reported in the "Capacity results tables" from the "Results" ribbon tab. These results are provided for each section of all Wall-stacks and are in the form of Demand Capacity ratios. PMM and shear tables are kept separate.

From the same tab, results can also be viewed graphically. Here Demand/ Capacity ratios are represented with a color coded graphic display of the structural model. Outputs from each limit state are kept separate.

Capacity results							
Beam design Column design Joint design Column PMM checks Beam V checks Column V checks Joint checks Wall PMM checks Wall V checks							
Wall	Section	Station [m]	Combination	N [N]	M2 [Nmm]	M3 [Nmm]	D/C
NUCLEO	-03	-3	QKE1	-1.623e+06	2.93e+09	-1.092e+09	0.923
	00	0	QKE1	-1.291e+06	2.93e+09	-1.092e+09	1.024
	03	3	QKE1	-9.649e+05	2.272e+09	-8.756e+08	0.806
	06	6	QKE1	-6.392e+05	1.708e+09	-6.902e+08	0.642
	09	9	QKE1	-3.118e+05	1.145e+09	-5.048e+08	0.472
	12	12	QKE1	-1.769e+05	5.813e+08	-3.194e+08	0.236
SETTOX1	-03	-3	QKE1	1.448e+05	-1.274e+09	-1.722e+07	0.954
	00	0	QKE1	-3.788e+05	-1.274e+09	-1.722e+07	0.681
	03	3	QKE1	-2.82e+05	-1.004e+09	-1.489e+07	0.544
	06	6	QKE1	-1.949e+05	-7.719e+08	-1.414e+07	0.440
	09	9	QKE1	-1.08e+05	-5.403e+08	-1.712e+07	0.321
	12	12	QKE3	-6.504e+04	3.512e+08	2.334e+07	0.224


3.10. The “Serviceability” Ribbon Tab

Codes have detailed provisions for three Serviceability Limit States:

- Stress limitation
- Crack control
- Deflection control

Of these, only the first two are addressed here. Deflection can be checked directly from SAP2000, being a direct result of the analysis.

Serviceability provisions are supported only in “Check” mode. No design is directly available.




3.10.1. Stress Limitation Checks of Single Frame Elements

The button “Check stresses” is used to run stress checks for a selected frame element, under proper service load conditions. The ensuing window shows the service load combinations and the resulting concrete and steel stresses. These are compared with code limits and results are provided as Demand Capacity ratios.

Calculations use the method of transformed section, with compression only concrete and linear stress strain relations. Sections are assumed to remain planar. The $n = E_s/E_c$ modular ratio of steel to concrete is specified from the “General Settings” ribbon tab.

Checks are provided for all service load combinations at all stations within a given segment. The segment is chosen by the user clicking the desired location from the graphics on the upper part of the window.

Additional load combinations can be assigned by the user, directly from this window.



3.10.2. Crack Control Check of Single Frame Elements


The button “Check cracking” is used to run crack control checks for a selected frame element, under proper service load conditions.

Based on EC2 provisions, the Service Limit States considered here are decompression, crack formation, and crack opening. The necessary code parameters are assigned from the “General Settings” ribbon tab.

Commands and output are sensitive to the selected code. NTC has different limit states and settings based on environmental conditions and protection of reinforcing.

Checks are provided for all proper service load combinations and at all stations within a given segment. The segment is chosen by the user clicking the desired location from the graphics on the upper part of the window.

Additional load combinations can be assigned by the user directly from this window.



Demand Capacity ratios for each load combination are provided comparing crack openings with W_{lim} .

3.10.3. Checks of All Frame Elements At Once


The previous commands refer to the check of single frame elements. This command runs the check of all frames at once, for both Stress limitation and Crack control. In order to execute this command, the geometry and reinforcing of all sections should be preliminarily defined.

The results are reported in the "Serviceability tables" from the "Results" ribbon tab. These results are provided for each segment of each frame element, while columns and beams tables are kept separate.

From the same tab, results can also be viewed graphically. Here Demand/ Capacity ratios are represented with a color coded graphic display of the structural model. Outputs from each limit state are kept separate.

3.11. The "Detailing provisions" Ribbon Tab

The detailing provisions, considered here, refer to limits of reinforcing and to concrete geometrical constraints. These provisions derive from both the concrete and the seismic sections of the code. Referring to the Eurocodes in particular, detailing provisions are taken from EC2 and EC8. Detailing provisions are supported only in "Check" mode. No design is directly available.



3.11.1. Check of Single Frame Elements

This command runs detailing provisions checks for a selected beam or column.

Results are immediately reported on the “Detailing and limits of reinforcing” window. This window provides very detailed information on all provisions addressed and on reasons of failure, if any. The relevant code section is reported as well. A green, red, and yellow color code marks checks that passed, failed, or not applicable.

Provisions refer to the following general topics:

- concrete section minimum dimensions;
- limits of longitudinal reinforcing, both minimum and maximum;
- limits of transverse reinforcing, both minimum and maximum;
- reinforcement ratios.

Detailing and limits of reinforcing		
Norm	Result	Details
Check minimum area of reinforcement at top bars	Not applicable	element not designed.
Check ratio ρ of compression steel	OK	
Check maximum diameter of longitudinal rebars at supports	Not applicable	Cannot check this provision. element 243 is connected to a joint without columns.
Check minimum area of longitudinal reinforcement	OK	
Check maximum area of longitudinal reinforcements	OK	
Check minimum area of stirrups/ties	OK	
Check stirrups/ties maximum spacing	FAILED	Spacing should be less than 11.25cm.
Check shear at critical region	FAILED	At critical regions, add diagonal cross reinforcing having As larger than 0.5804cm ² . Ref. 7.4.4.1.2.2.
Check element dimensions	OK	
Check minimum longitudinal rebars at corners	OK	
Check longitudinal reinforcement to cross section area ratio	OK	
Check minimum area of web reinforcement for T or L shapes	Not applicable	
Check minimum area of longitudinal reinforcement	OK	
Check maximum area of longitudinal reinforcements	OK	
Check minimum area of stirrups/ties	OK	
Check stirrups/ties maximum spacing	OK	
Check element dimensions	OK	
Check minimum longitudinal rebars at corners	OK	
Check longitudinal reinforcement to cross section area ratio	OK	
Check minimum area of web reinforcement for T or L shapes	Not applicable	
Check minimum area of longitudinal reinforcement	OK	
Check maximum area of longitudinal reinforcements	OK	
Check minimum area of stirrups/ties	OK	
Check stirrups/ties maximum spacing	FAILED	Spacing should be less than 11.25cm.
Check shear at critical region	FAILED	At critical regions, add diagonal cross reinforcing having As larger than 0.5804cm ² . Ref. 7.4.4.1.2.2.
Check element dimensions	OK	
Check minimum longitudinal rebars at corners	OK	
Check longitudinal reinforcement to cross section area ratio	OK	
Check minimum area of web reinforcement for T or L shapes	Not applicable	

3.11.2. Check of Single Joints

This button runs detailing provisions checks for a selected beam-column joint.

The results are immediately reported on the “Detailing and limits of reinforcing” window. This window is similar to that previously described and provides very detailed information on all the provisions addressed and on the reasons of failure, if any. The relevant code section is reported as well.

Provisions address the following general topics:

- minimum longitudinal reinforcing;
- minimum joint confinement reinforcing;
- reinforcement ratios.

3.11.3. Check of Single Walls

This button runs detailing provisions checks for a selected Wall-stack.

The results are immediately reported on the “Detailing and limits of reinforcement” window. This window provides very detailed information on all the provisions addressed and on the reasons of failure, if any. The relevant code section is reported as well.

Provisions address the following general topics:


- wall section minimum dimensions;
- minimum longitudinal reinforcing;
- minimum joint confinement reinforcing;
- reinforcement ratios.

3.11.4. Checks of All Frame Members At Once

The button “Check all” is used to run a check of all frame elements and all frame joints at once. Results are reported in the “Detailing” provision section of the “Results” ribbon tab.

3.12. The “Results” Ribbon Tab

This tab provides organized results from the design and check phases previously performed.



The “Results” commands are prearranged in four groups:

- Tables;
- Diagrams;
- Reinforcing layouts;
- Report.

All results can be exported for subsequent use on calculation reports.

3.12.1. Strength Tables

Strength design summaries for both design and check results are provided. Results are presented in spreadsheet format, with separate tables for beams, columns, joints and walls.

Design results provide minimum required reinforcing areas, while check results provide Demand Capacity ratios. *Only the worst case for each load combination is reported.*

Results for columns and beams are reported for each segment. Results for Wall-stacks are reported for each section. If one or more members are selected, results are reported only for those. If no selection is active, results are reported for all members.

3.12.2. Capacity Tables

Capacity design summaries for both design and check results are provided. The results tables are similar to those described above.

If one or more members are selected, results are reported only for those. If no selection is active, results are reported for all members.

3.12.3. Serviceability Tables

Serviceability check results summaries are provided. Tables are similar to those described above.

If one or more members are selected, results are reported only for those. If no selection is active, results are reported for all members.

3.12.4. Detailing Provisions Tables

This button provides summary tables of checks for detailing provisions. Results are presented as spreadsheets, with separate tables for beams, columns, joints and walls. Results for columns and beams are reported for each segment. Results for Wall-Stacks are reported for each section.

Name	Segment	Section	Length	Critical length	Check
104			3	0.61	
	1	PIL30x60	1		8/9
	2	PIL30x60	1		9/9
	3	PIL30x60	1		8/9
105			3	0.61	
	1	PIL30x60	1		8/9
	2	PIL30x60	1		9/9
	3	PIL30x60	1		8/9
108			3	0.46	
	1	PIL40x40	1		8/9
	2	PIL40x40	1		9/9

Results are reported in a passed or not passed format base on the number of checks that are satisfactory overall. Results are printed in green if all checks passed, otherwise in red. If checks do not apply to a given instance, results are printed yellow. A double click over one of the results opens a window with the detailed results checklist, similar to that described for single element checks.

If one or more members are selected, results are reported only for those. If no selection is active, results are reported for all members.

For each frame element, other information is reported, such as section ID and length of all segments.

3.12.5. Log Table

This command opens a table with a list of program-generated messages. The messages refer to errors or inconsistencies encountered during execution.


3.12.6. Delete results

This command deletes all the design and check results for all the elements of the model.

3.12.7. Show ratios

This command graphically displays the demand capacity ratios contours of frames and walls with reference to the selected limit states.

Frame results can be displayed considering the worst D/C ratio over the entire length of the element or on a segment by segment basis.



3.12.8. PMM 3D Interaction Diagram

This command opens a full 3D graphics with the PMM interaction diagram of the section selected on the main window. The representation can be further refined with tools recalled by the right click of the mouse.


3.12.9. Ellipse of Inertia

This command opens a graphic window with the diagram of the ellipse of inertia for the section selected on the main window. The maximum and minimum radii of inertia are reported.


3.12.10. Reinforcing layouts

This group of commands allow to display and export in .dxf/.dwg format the reinforcing layouts of beams, columns and walls.

The user can select a frame element and click on the “Display” command to visualize the reinforcing sketch of the selected beam or column. For columns, the user is required to select the preferred splicing location: either at the bottom or at mid-column. From the same window the user can export the single element or the layout of the entire beam or column row in .dxf/.dwg format.



If the user selects more than one frame or wall element, the corresponding beam and column rows and wall stacks can be directly exported in separated .dxf/.dwg files using the command “Export” of the ribbon menu.



Alternatively, by clicking on “Export rebars table”, it will be possible to create detailed rebars tables of the selected beams and columns row.


3.12.11. Report

Through this command it is possible to generate an extensive report which contains the details of the calculations performed for each structural element. The report is generated in Word format.

By clicking on the “Details” button, it would be possible to choose the units to be used in the document.

3.13. The “View” Ribbon Tab

Through this menu the user can customize the graphical preferences and navigate through 3D and 2D views.




The menu is divided in the following groups:

- View type;
- Set view;
- Show/Hide;
- Reinforcing contours.

3.13.1. View type

This group of commands allow the user to switch from extruded to wireframe view. In addition, by clicking on the “Advanced” button (beside the group’s name) the “View preferences” window will be shown. In this window the user can customize the colors and the size of the different elements. These settings are saved in the model file and maintained when the model is closed. To change the default color profile used when a new model is imported use the “Set color profile...” command.



3.13.2. Set view

These commands allow to switch in a plane view based on the local axes of the selected frame element.


3.13.3. Show/Hide

These commands allow to display or remove different components from the current view (e.g. origin, labels...).

3.13.4. Reinforcing contours

These commands allow to display color-coded views of the entire model related to the reinforcing currently assigned to beams and columns. The following contour maps are available:

- columns longitudinal reinforcing ratios;
- beams top longitudinal reinforcing ratios;
- beams bottom longitudinal reinforcing ratios;
- longitudinal reinforcing densities on beams and columns;
- shear reinforcing densities on beams and columns;
- total reinforcing densities on beams and columns.



3.14. Additional export capabilities

The following results can be exported for use on calculation reports:

*Summary of Results
tables for Strength,
Capacity,*

These tables can be obtained from the “Results” ribbon tab and can be exported to Excel spreadsheets using the corresponding button on the top of the table. These

<i>Serviceability and Detailing provisions</i>	<p>tables are kept updated while the user runs additional design/checks.</p> <p>Design tables provide minimum design areas for longitudinal and transverse reinforcing.</p> <p>Check tables provide Demand Capacity ratios from PMM and V checks of worst load conditions for all members, including frame segments, wall sections, and beam-column joints.</p>
<i>Frame internal forces tables</i>	<p>Internal forces tables for each frame element can be obtained from the “Define” ribbon tab. They can be copied and pasted to Excel spreadsheets.</p>
<i>2D Interaction diagrams</i>	<p>Interaction diagrams can be exported in EMF format (vector graphics used by Microsoft Word and other software). These are PM and MM interaction diagrams obtained during checks of single frame elements.</p>
<i>Interaction curves tables</i>	<p>Tables with point coordinates of interaction curves can be copied and pasted to Excel spreadsheets. They can be obtained clicking the “Copy” button during checks of single frame elements.</p>
<i>Export of complete input and output data tables</i>	<p>From the “File” menu by clicking the “Export” button, complete data tables for the model, including internal forces as well as design and check results can be exported to Excel or XML files. Note that these results occupy a single, very large worksheet.</p>
<i>Screen catches</i>	<p>Screen catches of reinforced sections, 3D interaction diagrams, color-coded graphics of results, Ellipses of Inertia, and all other figures generated by VIS, can be obtained using the Alt-Stamp button combination from the keyboard.</p>